Sewing Pattern — Bag 3020

Recommendations on fabric: well-shape stiff natural/mixed fabric

You will also need: fusing, lining, decorative cord, cardboard.

If the pattern has double contour the seam allowances are included.
Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

Fabric:

1. Upper part – 1 piece
2. Bottom – 1 piece

Lining:
1. Upper part – 1 piece
2. Bottom – 1 piece

Fusing: all fabric/lining details.

INSTRUCTIONS:
1. Apply the fusing to wring side of fabric/lining details.

2. Cut cardboard bottom without seam allowances.

3. Stitch upper part as a ring.

4. Stitch lining detail as a ring leaving a hole for turning the bag right side out.

5. Cut a handle of 40 cm length and 4 cm width. Fold it along the center wrong side out, fold edge allowances under and make a stitch at 0.1 from the edge.

6. Set loops as marked (outer detail).

7. Stitch lining upper part to upper part inserting the handle.

8. Fold upper part inside as marked. Make two parallel stitches around to create a coulisse. Upper stitch goes along loop's upper edge, lower one goes along lower edge.

9. Stitch the bottom to the bag. Stitch lining bottom to the lining.

10.Insert cardboard bottom into the bag fixing it with 2-3 stitches to lining bottom.

11. Turn the bag right side out through the hole. Stitch the hole.

12. Cut the cord into two equal parts. Set one of cords into the loop and, pull it through the coulisse and pull out from this loop. Do the same with another cord and another loop. Set tips on cord ends or tie them.

TECHNICAL DRAWING: