Sleeveless Dress - Выкройка #2470

Recommendations on fabric: natural/mixed fabric suitable for dresses.



You will also need: fusible interfacing; 5 buttons.

Seam allowances: all seams 1 cm; seam allowance for hem – 3 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back yoke - cut 1
2. Upper center back - cut 2
3. Upper side back - cut 2
4. Lower back - cut 2
5. Front yoke — cut 2
6. Upper center front — cut 2
7. Upper side front — cut 2

8. Lower front — cut 2
9. Side - cut 2
10. Pocket bag – cut 2
11. Center front facing- cut 2
12. Back neck facing – cut 1

Fusible interfacing:
1. Center front facing- cut 2
2. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew center edges on lower backs and on upper backs, press towards left and serge. Sew yoke to back, press towards top and serge. Sew side backs to center back, press towards center and serge.

3. Sew upper back to lower back, press seam allowances towards top and serge.

4. Sew front darts on front, press bulk towards top. Sew side fronts to front, press towards center and serge. Sew yoke to front, press towards top and serge.

5. Pin pocket bag onto lower front right sides together and sew pocket opening. Clip seam allowances, fold pocket bag onto wrong side, press. Pin lower front onto side and sew pocket bag edge, serge. Baste pieces together by боковому and верхнему срезам.

6. Sew upper front to lower front, press towards top and serge.

7. Sew shoulder and side seams, press towards the back and serge.

8. Sew shoulder edges of center front facings and back neckline facing, press the seam apart. Serge the outer edge. Pin center front facings onto garment right sides together and sew center front edge, neckline edge and the lower corner of the front piece. Clip into curves, trim away corners, turn pieces right side out, straighten, press.

9. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole edge from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.

10. Serge the lower edge of garment, press onto wrong side and topstitch.

11. Make the three upper button holes on the right front, sew on buttons on the left one. Make two button holes

on the left front skirt, sew on inner buttons on the right skirt accordingly.

Технический рисунок:



