

Sewing Pattern — Dress 5211

Recommendations on fabric: panne velvet of 150 cm width.

You will also need: elastic lace, lining, fusing, a zipper.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

ALL PANNE VELVET DETAILS MUST BE CUT OUT IN SAME DIRECTION (ALONG PILE DIRECTION)!

Fabric:

1. Middle back part – 2 pieces
2. Side back part – 2 pieces
3. Middle front part – 2 pieces
4. Side front part – 2 pieces
7. Middle back panel – 2 pieces
8. Side back panel – 2 pieces
9. Side front panel – 2 pieces
10. Middle front panel – 1 folded piece
11. Back neckline facing – 2 pieces
12. Front neckline facing – 2 pieces
13. Back armhole facing – 2 pieces
14. Front armhole facing – 2 pieces

Lace:

5. Back insert – 2 pieces
6. Front insert – 1 folded piece

Lining:

1. Middle back part – 2 pieces

2. Side back part – 2 pieces
3. Middle front part – 2 pieces
4. Side front part – 2 pieces

Fusing: Apply the fusing to wrong side of back neckline facing, front neckline facing, back armhole facing, front armhole facing.

INSTRUCTIONS:

1. Sew front/back relieve seams (fabric and lining). Tack lining and fabric details wrong sides together, and process as the single detail. Sew side/shoulder seams.
2. Sew side edges of lace inserts. Sew insert upper edges to lower edges of dress upper part right sides together. Press allowances upwards and slash middle front insert allowance.
3. Sew relieve/side seams of skirt. Sew middle back seam between hem and mark. Sew the skirt to lace insert's lower edge, press allowances towards the skirt.
4. Press closure slit allowance to wrong side, sew the zipper under slit edges.
5. Sew neckline facings together. Sew armhole facings together. Sew facings to garment right sides together. Fold facings out and topstitch on joining seam allowance at 1-2 mm from the seam; then press. Fold free edges of back neckline facings under and sew them to zipper braid. Fold lower ends of front neckline facing under and sew them to seam joining the insert.
6. Press hem allowance to wrong side and sew with blind stitches.

TECHNICAL DRAWING:

