

Sewing Pattern — Skirt 5180

Recommendations on fabric: nylon of 150 cm width;
companion lining of 150 cm width; polyester.

You will also need: zipper; 1 button; 2 studs; Velcro.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Front panel - 1 folded detail
2. Back panel - 2 details
3. Back yoke – 2 details
4. Front yoke – 1 folded detail
5. Pocket facing – 1 detail
6. Lower part of pocket – 1 detail
7. Upper part of pocket – 1 detail
8. Flap – 2 details
9. Waistband – 1 detail

Lining:

10. Front panel - 1 folded detail
11. Back panel - 2 details
12. Pocket facing– 1 detail
13. Lower part of pocket – 1 detail
14. Upper part of pocket – 1 detail

Polyester:

15. Front panel - 1 folded detail
16. Back panel - 2 details
17. Pocket facing – 1 detail
18. Lower part of pocket – 1 detail
19. Upper part of pocket – 1 detail
20. Waistband – 1 detail

INSTRUCTIONS:

1. Topstitch polyester details on corresponding lining details with rare stitch at 0.5 cm distance from edge.
2. Sew front panel and front yoke, press seam into yoke.
3. Sew pocket lower and upper parts to fabric facing. Fold the pocket into right side. Sew the flap and pocket lower main part right sides together. Fold into right side, work and press.
4. Sew pocket lining. Pull fabric pocket into lining and sew on upper edge. Do not sew lining edge the flap will be sewn to. Fold pocket lining into the pocket; sew pocket lower edge to pocket lower lining by hand.
5. Topstitch pocket flap, Velcro on the marking, and pocket ribs. Make upper stud into the pocket and lower one into front panel.
6. Sew front panel to lining along the left side seam down from the vent mark; topstitch the garment hem and right side seam up to the mark. Cut side seams near marks, cut polyester out from seams, then fold into right side. Work seams and corners, then press.
7. Sew yokes to back panels, cut polyester out, press seams into yokes. Sew back center seam (fabric) to the yoke, then cut polyester out and press seam apart.
8. Sew zipper into back yoke.
9. Sew back center lining seam up to the zipper mark. Cut polyester out and press the seam apart.
10. Sew back fabric panel and lining one along left side seam from mark down to the vent. Topstitch garment hem and sew right side seam upwards the vent up to the mark. Cut side seams, cut polyester out of seams and fold into right side. Work seams and corners, then press.
11. Fold lining zipper allowance under and sew it to zipper band.
12. Sew front and back panels right sides together (fabric seams), press seams apart. Fold the garment so that lining details were right sides inside, then sew side seams. Cut polyester out and press seams apart. Fold the skirt into right side.
13. Topstitch vent on the front panel according to marking, topstitch Velcro.
14. Topstitch polyester from wrong side of waistband. Fold the waistband along its center and sew short ends. Tuck the waistband. From right side, make two holes for ties in accordance with marking.
15. Fold ties along the center and sew long and short edges. Fold into right side, work and press.
16. Pull ties into holes and sew them from wrong side near side seam.
17. Sew waistband and waistline right sides together. Cut polyester out of seam, press seam into waistband. Fold under the seam allowance of the open waistband edge overlapping the joining seam and topstitch closely along the edge.

18. Work button hole and sew button in accordance with marking.

TECHNICAL DRAWING:

