

## Sewing Pattern — Skirt 4295

Recommendations on fabric: natural or mixed well-draping suit fabrics.

You will also need: fusible interfacing, invisible zipper.

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

#### Main fabric:

1. Back yoke – cut 4
2. Back skirt – cut 2
3. Front yoke - cut 2
4. Front skirt – cut 1
5. Side front skirt/pocket - cut 1
6. Pocket bag - cut 1
7. Right facing of lower back – cut 1
8. Left facing of lower back – cut 1
9. Facing of lower front – cut 1

#### Fusible interfacing:

1. Back yoke – cut 2
2. Front yoke - cut 1
3. Right facing of lower back – cut 1
4. Left facing of lower back – cut 1
5. Facing of lower front – cut -1

### **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew darts on back skirt sections. Press towards center. Stitch outer back yokes to back sections, press seam allowances upwards.
3. Serge center edges of backs separately, serging the vent at the same time. Sew center back seam from the zipper notch down to the edge of the vent. Press seam allowances apart, including the opening for zipper. Press seam allowances of the vent to left side edge. Press right side of the vent at 1 cm. Tack seam allowances of the vent with machine stitch. Sew in the zipper.
4. Make pleats on front under the pocket opening (folds are pressed downwards). Place pocket bag on front, right sides together, and sew to pocket opening. Turn pocket bag to wrong side, straighten, press.
5. Pin Side front/pocket to front at waist edge at marks. Sew lower and vertical edges of pocket bag to side front/pocket. Serge edges. Align and baste to waist and skirt side.
6. Sew the long triangular dart of front skirt, serge. Make a pleat above the dart, baste.
7. Make the rest of pleats on front skirt (folds are pressed downwards). Topstitch them on front part according to technical drawing. Stitch outer front yoke to front skirt.
8. Sew side seams, press seam toward back and serge.
9. Sew side seams of inner yokes. Serge lower edge. Sew the inner yoke to outer yoke along top edge. Press seam toward inner yoke, understitch. Turn to inside, press. Slipstitch edges of inner yoke to zipper tape. Topstitch inner yoke into outer yoke connecting seam.
10. Sew side seams of lower facings, press seam allowances apart. Serge upper edge. Stitch facings to seam allowances of the vent, Trim corners, press seam onto the facing. Understitch. Turn the facing under, straighten corners, press. Slipstitch.

### **TECHNICAL DRAWING:**

