

Sewing Pattern — Jacket 5103

Recommendations on fabric: suiting with or without lycra

You will also need: lining; fusible interfacing; 4 flat buttons; shoulder pads; a piece of polyester batting

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 3 cm on hem, 1 cm on all other seams

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Front - cut 2
2. Back - cut 2
3. Upper sleeve -cut 2
4. Elbow sleeve -cut 2
5. Collar - cut 2
6. Back neck facing - cut 1
7. Pocket - cut 2
8. Button-stand facing - cut 2

Lining:

1. Front - except for the width of button-stand facing
2. Back - except for the width of neck facing and width of pleat on center line of 2 cm deep;
3. Upper sleeve, elbow sleeve, and pocket - except for the width of pocket facing

Fusible interfacing: front, button-stand facings, back neck facing, collar and pockets; on details of sleeves –self- facings (cuffs). Additionally apply fusing to lower edge of back.

INSTRUCTIONS:

1. Sew center back seam. Press seam allowances apart.
2. Sew darts. Press waist darts toward center. Press bust darts downward toward hem.
3. Sew side and shoulder seams. Press seams open. Sew back neck facing to button-stand facings.
4. Pin facing to jacket, right sides together. Lapels of button-stands should be a bit wider than lapels of front. Sew button-stand facing from lower edges of front (leaving 5 cm to ends of button-stands) to edges of front bands and lapels up to the cross notch. Pin collar right sides together, and sew outer edges. Top collar should be a bit wider than lower one. Insert collar between jacket and facing. Sew lower collar to the jacket neckline, sew top collar to the neckline of the facing. Press seam allowances of top and lower collars connecting seams; clip into curves. Turn button-stand facing onto wrong side and press. Press seam allowance on hem of jacket onto wrong side, but do not sew yet. Pin together connecting seams of top and lower collars. Turn back neckline facing upwards again and sew allowances connecting seams of top and lower collars close to seams.
5. Sew lining of each pocket to self-facing of pocket top, leaving a section of approx. 5 cm open in the center of the seam. Turn self-facing of pocket top and lining onto right side of pocket, press, and topstitch side and lower edges. Sew the open section closed. Pin the pocket onto front part according to markers and sew by hand with invisible stitches.
6. Sew front seams of sleeves. Turn self-facing of lower edge of sleeve onto right side of sleeve and stitch along edges up to slit marker. Turn upper edge of facing downwards and pin. Sew elbow sleeve seam up to the slit. Sew open edges of the facing. Turn facing onto wrong side. Press lower edge of sleeve and slit edges.
7. Make a gathering stitch along sleeve cap for ease. Sew sleeves to armholes, matching marks and adjusting ease. Sew a polyester batting tape of approx. 4 cm wide under seam allowances of each sleeve connecting seam on rounded section. Sew in shoulder pads.
8. Make a pleat on back lining and fasten it under neckline and a few cm above the turn up line of the hem.
9. Sew darts on lining. Sew lining the same way as main fabric, leaving a section of about 20 cm unsewn in elbow seam of one of the sleeves. Pin lining to main garment right sides together, aligning along center of back and shoulder seams. Sew main garment to lining along button-stand facings and neckline. Stitch lining to lower edges of sleeves. Make a drape pleat along the edge of the garment and stitch lining to hem edge. Turn garment out through the unsewn section of sleeve, stitch this section closed.
10. Make buttonholes according to markers on right front. Sew buttons on left.
11. Turn lower edges of sleeves upwards the length of slit, to form the cuffs.

TECHNICAL DRAWING:

