

Sewing Pattern — Coat 5087

Recommendations on fabric: fabric of 150 cm width (suitable for coats)

You will also need: lining of 140 cm width; fusing; 5 buttons of 20 mm diameter; 6 buttons of 15 mm diameter; shoulder pads.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Flap – 2 pieces
2. Center back part – 2 pieces
3. Side back part – 2 pieces
4. Side front part – 2 pieces
5. Back neckline facing – 1 piece
6. Pocket facing – 4 pieces
7. Collar – 2 pieces
8. Center front part – 2 pieces
9. Front band – 2 pieces
10. Upper sleeve – 2 pieces
11. Lower sleeve – 2 pieces

Lining:

Cut front parts excluding front bands' widths. Cut lower sleeves with seam allowance only. Cut back part excluding the width of back neckline facing.

12. Upper sacking – 2 pieces
13. Lower sacking – 2 pieces
14. Flap – 2 pieces

Fusing: apply the fusing to wrong side of front bands, back neckline facing, inner collar and flaps. Apply the fusing additionally to wrong side of back hem.

INSTRUCTIONS:

1. Stitch middle back seam down to the vent. Press vent's one-piece facing (left back part) into wrong side along bending line, then sew it to allowances; topstitch left detail along the seam. Press vent's one-pieces facing at right allowance into wrong side, sew it to hem allowance. Pin vent's edges along coinciding lines.
2. Stitch front/back relieves, press allowances apart.
3. Cut slit "frame" pockets with two facings and flaps into front part: stitch neatly one fabric/one lining flaps along side/lower edges. Topstitch along edges. Apply fusing stripe of 4 cm width on wrong side of front part (above pocket marking). Lay two pocket facings on front part right sides together; pin along pocket entrance marking and stitch (lengthwise edges of facings must coincide with middle line of pocket marking). Cut front part between stitches, diagonally at stitch ends. Do not cut through facing! Press slit edges contrariwise entrances. Turn facings to wrong side through slit to make a neat frame, than tack (facing bendings meet at centers of pocket entrances.) Topstitch along joining seams. Turn small triangles at slit ends into wrong side and stitch strictly to facings between upper stitch ends and lower stitch ends, stitch together at facing side seam's side. Lay flaps' open edges between facings and stitch along seams joining upper facings. Stitch sackings on wrong side to allowances of seams joining flaps/allowances of seams joining lower facings. Cut sackings, adjust them and stitch them together.
4. Stitch shoulder/side seams.
5. Stitch inner collar into neckline; stitch shoulder seams of back facing and front bands, stitch outer collar into facing neckline and front bands; press allowances apart, slash at rounding.
6. Lay outer collar joint with front bands on the garment (right sides together), then overstretch edgings and the collar as well as armholes; turn right side out and press; sew allowances of outer collar's edge on neckline allowance. On right side: turn edging and collar right side out and tack.
7. At hem, lay front bands frontward. Fold hem allowance into wrong side and sew. Fold front bands into wrong side. Topstitch front bands and the collar t 1.0 cm distance
8. Apply the fusing to wrong side of sleeves' hems. Stitch upper sleeves to sleeves' elbow part; press allowances apart and turn sleeves right side out. Press sleeve hem allowances into wrong side.
9. Stitch sleeves into armholes: ease sleeve cap slightly between marks and pull the cord till sleeve cap coincides to armhole. Moist the fabric and iron pleats. Pin sleeves to the garment coinciding marks. Stitch sleeves to garment at sleeve side. Sew shoulder pads.
10. Stitch lining details together. Stitch the lining to sleeve hems, inner edges of front bands and to back neckline facing. At vent, pin the lining carefully. Cut the lining around the vent correspondingly; pay attention on allowances. Fold lining edges under and sew them to vent's edges. Sew the lining under.
11. Make buttonholes into right front part, sew buttons on left one.

TECHNICAL DRAWING:

