

Sewing Pattern — Raincoat 5078

Recommendations on fabric: fabric of 150 cm width suitable for raincoats

You will also need: lining, fusible interfacing, raglan shoulder pads

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance:

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Fabric:

1. Back – cut 2
2. Back neck facing – cut 1 on fold
3. Front – cut 2
4. Off-set welt – cut 2
5. Front – cut 2
6. Collar – cut 2
7. Valance – cut 2
8. Back sleeve – cut 2
9. Front sleeve – cut 2
10. Belt – cut 1

Lining:

11. Back – cut 2
12. Front – cut 2
13. Back sleeve – cut 2
14. Front sleeve – cut 2
15. Pocket Sacking – cut 4

Fusible interfacing: apply the interfacing to wrong side of front self-facings, back neck facing, collar and off-set welts. Additionally, apply a strip of interfacing to hem allowance.

INSTRUCTIONS:

1. Make off-set welt pockets on front: sew welt outer edges, turn right side out and press. Topstitch along edges. Apply fusible strip of 4 cm width to wrong side of front (above pocket marking). Fold one long edge of valance under, and topstitch the valance on upper sacking. Lay off-set welt and upper sacking on front right sides together; pin along pocket entrance marking and stitch (lengthwise edges of facings must coincide with middle line of pocket marking). Cut front between stitches, snipping diagonally toward end of stitching. Do not cut through off-set welt and sacking! Press seam allowance apart. Turn off-set welt and sacking onto wrong side through opening, then tack. Lay lower sacking on front wrong side on the welt (sacking faces up); topstitch the welt on right side along joining seam catching the sacking. Press the sacking downward. Turn small triangles at slit ends onto wrong side and stitch strictly to facings between upper stitch ends and lower stitch ends. Trim sackings, adjust and sew together. Topstitch off-set welts on front along short edges.
2. Sew raglan seams into front/back, topstitch at 1.0 cm distance.
3. Sew sleeve upper seam. Sew lower seam of sleeve and garment side seam with one continuous stitch.
4. Sew inner collar to neckline, right sides together. Sew shoulder seams of back neck facing and front self-facing, sew outer collar to facing neckline and front self-facing. Clip into curves and press allowances apart.
5. Lay outer collar joint with front self-facing on the garment (right sides together), then sew edgings and the collar. Turn right side out and press. Fold outer collar's edge under and topstitch it on neckline. On right side: turn edging and collar right side out, tack, then press.
6. At lower edge: pin front self-facing, right sides together, to front. Fold hem allowance onto wrong side and sew. Trim corner and turn self-facing right side out. Topstitch center front and the collar at 1.0 cm.
7. Sew in shoulder pads.
8. Sew lining together same as main fabric. Sew the lining to sleeve hems, and inner edges of facing. Pin the lining near vent carefully. Sew the lining under.
9. Fold the belt along the center, right sides together, and sew along one long and one short side, turn right side out and press. Turn open edge to the inside, and topstitch belt perimeter at 0.5 cm distance.

TECHNICAL DRAWING:

