

Sewing Pattern — Blouse 5033

Recommendations on fabric: soft cotton/linen/viscose

You will also need: 9 buttons

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Front part one-piece with collar – 2 details
2. Front band one-piece with collar – 2 details
3. Back part – 1 folded detail
4. Sleeve – 2 details
5. Cuff – 2 details

Additionally: 2 pipings for sleeve slits (16 cm length and 2 cm width each)

Fusing:

1. Front band one-piece with collar – 2 pie details
2. Cuff – 2 details

INSTRUCTIONS:

1. Stitch front upper darts.
2. Stitch shoulder seams up to the corner (mark). Slash front shoulder seam allowance up to stitch end (toward the corner).
3. Cut sleeves as marked. Process slit edges with the piping, width is 0.5 cm. Cut the piping diagonally at slit's top (sleeve's wrong side). Stitch sleeves into armholes. Stitch sleeve/side seams with one stitch, leave side seams' lower segments open for slits.
4. Stitch middle back seam into inner one-piece collar. Stitch inner collar into back neckline. Lay outer collar and front bands on inner collar and front parts right sides together, stitch front edgings and collar's outer edges together; cut seam allowances into collar corners diagonally; slash corner allowances between the collar and front edge.
5. Press the hem/slit allowance/front bands' lower edges into wrong side.
6. Fold front bands inside, turn the collar right side out. Fold outer collar's lower edge under and stitch to joining seam (to do this, slash left shoulder's allowances up to the corner).
7. Sew front bands' upper edges to shoulder seam allowances, sew lower edges to hem allowance.
8. Topstitch hem allowance and side slits at 0.75 cm. Topstitch front edgings and the collar along edges.
9. Make pleats into sleeve hems laying x on o, then tack them.
10. Fold cuffs along the center, process short edges neatly. Stitch long edge to sleeve hems' right side catching the piping of slit front edge. Fold inner cuff under and stitch to joining seam.
11. Make 7 long buttonholes into right front edging, make 2 buttonholes into each cuff at 1 cm from shirt front edge.
12. Sew buttons on left front edging so that they were on buttonhole's top.

TECHNICAL DRAWING:

