

## Sewing Pattern — Jacket 5011

Recommended fabric: suiting fabric.

You will also need: lining; 1 button

If the pattern has a double line around it, the seam allowances are included.

Seam allowance: 2 cm on garment hem; sleeve hem; all other seams 1 cm.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

### Main fabric:

1. Pocket welt (valance) – cut 2
2. Back – cut 2
3. Back neck facing – cut 1 on fold
4. Front – cut 2
5. Center front facing – cut 2
6. Sleeve – cut 2

### Lining:

7. Sleeve – cut 2
8. Back – cut 2
9. Front – cut 2
10. Pocket sacking – cut 2

Fusible interfacing: front facings, back neck facing, fronts. Apply interfacing to wrong side of front facings, back neck facings, fronts.

**INSTRUCTIONS:**

1. Sew back and front darts, press toward center. Sew center back seam and press open.
2. Making welt pockets: Apply strip of fusible interfacing 4 cm wide to wrong side of pocket marking. Lay pocket facings on front, right sides together. Pin along pocket entrance marking and sew. Cut the front between stitches, snipping diagonally toward stitch ends. Press seam allowance apart. Fold facings onto wrong side through the slit to make a neat frame, then tack. Pin the sacking on wrong side on lower frame, fold the sacking upwards; topstitch the sacking on right side of front catching sacking. Press the sacking downward. Lay the second edge of sacking on wrong side of pocket and topstitch it on right side along the seam joining upper facing. Turn small triangles at slit ends onto wrong side and topstitch accurately between upper stitch ends and lower stitch ends. Stitch facings open edges. Here is a great video tutorial that illustrates how to easily construct a [double welt pocket](#).
3. Sew shoulder/side seams. Press seams apart.
4. Sew front facings to back neck facing at shoulder seams. Press seams apart
5. Pin front facing to front and neckline, right sides together, and sew. Clip into curves and trim corners. Understitch, and press toward wrong side of garment.
6. Serge or finish garment lower edge and press along hem line.
7. Sew sleeve seams. Press seams apart. Make a gathering stitch along sleeve cap for ease. Sew sleeves into armholes, matching marks and easing along sleeve caps.
8. Sew shoulder pads.
9. Sew darts on lining front/back, sew lining seams. Sew the lining to sleeve hems, outer edges of front facing/back neck facing. Serge the lower edge of lining, turn onto wrong side, and topstitch.
10. Make buttonhole on right front, sew button on left one. Topstitch garment as suggested in diagram, if desired.

**TECHNICAL DRAWING:**