

Sewing Pattern — Coat 5007

Recommendations on fabric: fabric of 150 cm width suitable for coats

You will also need: lining, fusible interfacing, 5 buttons, shoulder pads

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem allowance is marked on pattern

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Center back – cut 1 on fold
2. Side front/sleeve– cut 2
3. Side back/sleeve – cut 2
4. Center front – cut 2
5. Front band facing – cut 2
6. Turn-down collar – cut 2 on fold
7. Back neck facing – cut 1 on fold
8. Flap – cut 4
9. Pocket sacking – cut 4

Lining:

1. Center back – cut 1 on fold (excluding width of back neck facing)
2. Center front – cut 2 (excluding width of front band facing)
3. Side front/sleeve – cut 2
4. Side back/sleeve - cut 2

Fusible interfacing: Apply fusible interfacing to wrong side of front band facings, back neck facing, collar, and 2 flaps. Additionally, apply the interfacing to hem allowance.

INSTRUCTIONS:

1. Sew side backs/sleeve to center back. Topstitch on right side along back seam.
2. For pocket: slash front seam allowances diagonally in corners, then process lining sacking to front pocket entrance. Sew two flaps right sides together. Sew outer edges and turn right side out. Pin flap upward and tack it to front/sleeve lower part. Sew the sacking and the flap and press them downwards, press joining seam allowances upward. Sew center front to side front/sleeve and sewing sackings with the same seam. Topstitch front seams on right side. Tack sacking side edges to front parts.
3. Sew shoulder and sleeve upper seams. Press seams apart.
4. Sew inner collar to garment neckline. Sew shoulder seams of front band facing and back neck facing, press seams apart. Sew outer collar to neckline of facing.
5. Pin facing to center front, and inner collar to outer one along edges, right sides together and sew. Press the seam joining inner collar and the seam of back neck facing apart and stitch them together. Sew front band facing to coat along hem line.
6. Sew side seams and lower sleeve seams. Turn allowance for garment hem under, and slip-stitch.
7. Press sleeve hem under.
8. Sew in shoulder pads.
9. Sew lining same as main fabric. Sew the lining to inner edges of the facing and to sleeve hems. Turn lower edge of lining under, and topstitch. Turn garment right side out and press.
10. Make buttonholes on right front, sew buttons on left one.

TECHNICAL DRAWING: