

Sewing Pattern — Roll neck 6130

Recommendations on fabric: low to medium-stretch knit fabric.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: on hem and hem of sleeves — 1.5 cm, all other seams - 0.8 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.



When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Fabric:

1. Front – cut 1
2. Back – cut 1
3. Sleeves – cut 2
4. Collar – cut 1

Before sewing please check your head gets through the stitched into the ring.

Advice:

Knit fabric pieces are sewn together with special stretch-stitch or narrow zig-zag stitch. Seam allowance on hem is stitched with twin needles to save stretchiness. Pieces can also be sewn together with 3 or 4 – thread serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

INSTRUCTIONS:

1. Sew shoulder edges. Serge seams and press on back.
2. Sew sleeves into open armholes, matching notches. Serge the seam and press toward sleeve. Sew sleeve edge and side edge at one step.
3. Fold collar into ring, right side inside and sew. Turn collar out, fold in half wrong side inside. Sew collar into neckline, matching notches. Side edge of collar is near left shoulder seam. Serge and press collar connecting seam.
4. Serge hem of the garment and hem of sleeves. Turn hems under and topstitch.

TECHNICAL DRAWING: