

Sewing Pattern — Sport jacket 6123

Recommendations on fabric: whipcord;

You will also need: lining (jersey, fleece); warmer; fusing; 1 separable zipper (depending on front length including stand-up collar's height); trimming cord; elastic braids of 4.5 cm cuffs; elastic braid for jacket's hem; 2 holder for cord.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: 1 cm for all seams, 4.5 cm for garment/sleeve hems of upper part; 0 cm for lining hem (lining reaches hem line).

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

(On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Main fabric:

1. Front part – 2 pieces
2. Back part – 1 piece
3. Back yoke – 1 piece
4. Front yoke – 2 pieces
5. Back insert – 1 piece
6. Back insert_2 – 1 piece
7. Front insert – 2 pieces
8. Front insert_2 – 2 pieces
9. Sleeve – 4 pieces
10. Sleeve insert – 4 pieces
11. Collar – 2 pieces
12. Cuff – 2 pieces
13. Front band – 2 pieces
14. Large sacking – 2 pieces
15. Small sacking – 2 pieces
16. Off-set welt – 2 pieces



Cut bias 2 fabric stripes of 3.5 cm width for trimming. Stripes' length depends on trimming's length. NB! After trimming is ready, there must remain seam allowance of 1 cm. Otherwise, one must regulate width of cut stripes self.

Lining:

- 17. Front part – 2 pieces
- 18. Back part – 1 piece
- 19. Sleeve – 2 pieces

Warmer:

Topstitch the warmer along contour of outer collar details cut of warmer (1 piece) and waistband placket.

INSTRUCTIONS:

1. Stitch stripes together, press seams. Fold ready stripe along the center, insert the cord and make a stitch along cord contour's.
2. Apply the fusing to wrong side of off-set welt, press it along the center. Apply the fusing to pocket place. Mark a line determining ready welt's width on the welt. Topstitch the trimming on welt's right side; topstitch small sacking on welt's inner side. Lay the welt with sacking on right side of front part coinciding pocket marking lining and line on welt. Welt's outer side must coincide with right side of side front part. Stitch the welt. Stitch large pocket to pocket's upper marking. Cut pocket entrance between marking lines diagonally towards pocket marking's corners. Turn pocket details wrong side out. Press seam allowances. Stitch large sacking to zipper's upper braid. Stitch sackings' edges. Sackings' edges must enter into seam joining the zipper and the seam joining the waistband.
3. Stitch front/back inserts to front/back yokes inserting the trimming, then topstitch. Stitch yokes to sleeve details. Topstitch the seam along sleeves. Stitch inert_2:s to front/back parts. Topstitch along front/back parts. Stitch sleeve inserts to front/back parts, then topstitch. Stitch yokes to front/back parts, them topstitch. Stitch shoulder edge going over sleeve's center seam. Topstitch shoulder seam at back part. Stitch side seams and sleeves seams together. Stitch outer collar into neckline.
4. Press inner edge of front band into wrong side and topstitch front band on front part's lining. Stitch lining parts together. Stitch inner collar into lining neckline.
5. Stitch cuffs and elastic braid into rings separately. Insert elastic braid into cuffs, stretch it to cuff's length and make 2 decorative stitches.
For manufacture stitching, first fix elastic braid into cuffs, and then stitch them into a ring. Stitch cuffs to sleeve catching elastic braid's edge into the seam.
6. Lay one part of zipper on edging right sides together (directing teeth from edging). Overstitch edgings and collar edges with lining inserting the zipper. Turn the garment right side out.
7. Stitch the lining to cuffs.
8. Make holes for the cord into hem lining. Press the hem first at 1 cm, then 3.5 cm under. Topstitch the hem.
9. Topstitch edgings and the collar.

10. Press ready jacket.

11. Pull the cord into jacket hem (wrong side).

TECHNICAL DRAWING:

