

Sewing Pattern — Jacket 4162

Recommendations on fabric: lightweight fabric suitable for jacket in two colors

You will also need: fusible interfacing; 1 button; lining; shoulder pads; sleeve heads

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 3 cm on sleeve hem; 1 cm on all other seams

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric 1:

1. Center back – cut 2
2. Center front – cut 2
3. Upper sleeve – cut 2
4. Lower back facing – cut 1
5. Lower collar - cut 1
6. Upper collar – cut 1
7. Front band facing –cut 2
8. Back neck facing – cut 1
9. Off-set pocket welt – cut 2

Fabric 2:

1. Side front – cut 2
2. Side back – cut 2
3. Lower sleeve – cut 2

Lining:

1. Center front – cut 2
2. Side front - cut 2
3. Center back – cut 2
4. Side back – cut 2
5. Large pocket bag- cut 2
6. Small pocket bag- cut 2
7. Upper sleeve – cut 2
8. Lower sleeve – cut 2

* Lining is cut excluding the width of facings.

Fusible interfacing: center fronts, front band facings, lower back facing, back neck facing, upper collar, welts, seam allowance of sleeve hems.

INSTRUCTIONS:

1. Apply interfacing to listed pieces.
2. On back, sew and press darts towards center. Sew side backs to center backs, clip into curves and press seams open. Sew center back seam, press seam apart. Sew side fronts to center fronts. Clip into curves and press seams open.
3. Mark the place for pocket. Apply a strip of fusible interfacing to wrong side of pocket opening. Press off-set welt in half lengthwise wrong sides together. Topstitch smaller pocket bag onto inner side of off-set welt. Sew off-set welt to front along lower marking line of pocket. Sew large pocket bag to front along upper marked line of pocket. Start and end stitching at short marking lines. Cut opening into pocket. Make diagonal snips toward end of stitching. Turn off-set welt and big pocket bag onto wrong side through the slit opening. Fasten ends of pocket from the wrong side with double backstitch in corners. Sew edges of pocket bags. Here is a great tutorial for the [single welt pocket](#).
4. Sew shoulder and side seams of garment, press seams apart.
5. Pin top collar to lower collar right sides together, and sew outer edges, starting and stopping stitch exactly at the marked line of sewing in collar. Trim seam allowances in corners. Turn collar right side out, straighten and press.
6. Sew shoulder seams of back neck facing and front band facing, press seams apart. Sew lower back facing to front band facing, press seams apart.
7. Pin facing onto garment, right sides together, sew lower back and center front up to the notch marking the end of sewing in collar. Trim seam allowances of top and lower corners, clip into curves and understitch. Turn facing onto wrong side of garment, straighten and press.
8. Sew lower collar into the neckline of garment, and sew top collar into the neckline of facing.
9. Sew and press apart sleeve seams. Press hem allowance of sleeve.
10. Make a gathering stitch along sleeve cap for ease. Sew sleeves into armholes matching notches and adjusting ease. Sew in shoulder pads and sleeve heads.
11. Sew lining same as main fabric, leaving a slit in front right seam of sleeve.
12. Sew lining to inner facing edges. Press apart the collar seam allowances and fasten them close to the seams.
13. Sew lining to sleeve hems. Turn garment right side out through the slit in sleeve. Sew the slit in sleeve.
14. Make buttonholes on right front, and sew buttons on left front.

TECHNICAL DRAWING:

