

Sewing Pattern — Shirt 6027

Recommendations on fabric: shirting (cotton)

You will also need: fusible interfacing; 7 shirt buttons.

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: 1 cm, hem 1.5

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Yoke – cut 2
5. Collar-stand – cut 2
6. Collar – cut 2
7. Left pocket – cut 1

Note: If you are using plaids, stripes, or checks, purchase extra fabric, for matching at seams.

Fusible interfacing: left/right front plackets; collar-stand and collar

INSTRUCTIONS:

1. Apply interfacing to left/right front plackets; collar-stand and collar.
2. Serge upper edge of pocket, turn onto wrong side along fold line. Sew side edges and continue stitching along sides and bottom edges. Use this stitch as a guide for pressing seam allowance under. Turn top edge of pocket right side out. Press and turn under seam allowance.

3. Topstitch pocket to left front according to guidelines.
4. Press front seam allowance along marked line onto wrong side, fold and press again, along marked line. Baste in place. Topstitch from right side of garment.
5. Sew the pleat on back, press and tack along edges.
6. Lay yokes, right sides together, insert upper edge of back between them and sew together, matching marks. Turn right side out, press and topstitch.
7. Sew the front yokes to fronts in the same way. Press and topstitch.
8. Sew sleeves into armholes, matching marks. Serge and press toward the armhole and topstitch to the garment.
9. Sew side seams. Serge and press edges toward back and then topstitch.
10. Apply interfacing to one collar-stand and one collar. Sew collars, right sides together, along outer edges. Trim corners and clip into curves. Turn right side out, press and topstitch. Lay both collar-stands, right side together, inserting the ready collar between them. Sew together, including collar-stand ends. Clip into curves. Press inner collar-stand seam allowance onto wrong side. Sew outer collar-stand to neckline edge. Clip into curves and press toward collar. Topstitch inner collar-stand to joining seam. Topstitch collar-stand outer edges.
11. Press sleeve hem onto wrong side, fold the edge under, and sew at 1.5 cm distance. Do the same for the shirt hem.
12. Make buttonholes on left front side and collar-stand. Sew buttons on right.

TECHNICAL DRAWING:

