

## Sewing Pattern — Sweatshirt 7100

Recommendations on fabric: fleece, footer

You will also need: 1 regular zipper; tabs; decorative cord (see approximate length along the hood on the pattern)

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

**SEAM ALLOWANCE:** 1 cm for all seams, 3 cm for garment/sleeve hems/pocket entrance/hood's outer edge

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

Fabric:

1. Front part – 1 piece
2. Back part – 1 piece
3. Pocket – 2 pieces
4. Back sleeve – 2 pieces
5. Hood side – 2 pieces
6. Hood center – 1 piece
7. Front sleeve – 2 pieces

### **INSTRUCTIONS:**

1. Stitch hood sides to hood center and neaten seams. Neaten hood loops. Fold hood's outer allowance into wrong side, fold it under and topstitch on the hood.
2. Neaten the pocket along the contour and press it according to the pattern. Fold pocket entrance's allowance into wrong side and topstitch it at 2.5 cm from the edge. Lay the pocket on front part and topstitch.
3. Make a slit into front part between zipper's marking stopping 1 cm before hem mark. Make diagonal slit at mark's ends. Neaten long edges and press into wrong side. Lay the zipper under slit edges and stitch it. Topstitch zipper's allowances at 05 cm distance.

4. Stitch sleeve's upper edge and neaten it. Stitch sleeves into armholes according to notches. Stitch side seams and sleeves' lower seams with one stitch. Neaten seams and press them backwards.

5. Stitch the hood into the neckline. Neaten allowances.

6. Press sleeve hem under. Fold sleeve allowance into wrong side and press first at 1 cm and then at 2 cm. Topstitch pressed allowance on the sleeve.

7. Press garment's hem first at 1 cm and then at 2 cm. Fold it into wrong side and topstitch. Pull the cord into hood's loops and set tabs.

### **TECHNICAL DRAWING:**

