

## Sewing Pattern — Shorts 7080

Recommendations on fabric: velour/denim

You will also need: fusible interfacing; elastic braid; Velcro

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowances: 1 cm for all seams, 3 cm for hem, 5 cm for panel upper edge, 3 cm for panel front edge.

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

#### Main fabric:

1. Front part – 2 pieces
2. Back part – 2 pieces
3. Waistband – 1 piece
4. Panel – 1 piece

Interfacing: waistband.

### **INSTRUCTIONS:**

1. Apply interfacing to waistband.
2. Fold panel upper/middle/lower edges into wrong side and sew them under by hand (with edge closed).
3. Neaten front/middle/lower edges, side/inside leg edges of front/back parts. Stitch leg inside seams and press them apart. Stitch left side seam and press it apart.

4. Stitch front edge and back edges. Make another stitch along crotch seam close to seam joining front seam and back seam.
5. Press the waistband along the center, right side out, and neaten lower inner edge.
6. Stitch waistband raw edge to panel upper edge. Cut elastic braid and pull it into waistband back part. Fix elastic braid along side seams.
7. Lay back part right side edge on panel side edge and neaten them. Neaten right side edge of shorts front part. Stitch garment right side seam.
8. Topstitch waistband lower neaten edge on joining seam and press ready waistband. Press hem allowance into wrong side and topstitch. Topstitch Velcro on shorts and on panel according to marks.

**TECHNICAL DRAWING:**

