

## Sewing Pattern — Jacket 8003

Recommendations on fabric: natural or mixed - suiting fabric

You will also need: interfacing; 4 buttons; lining; shoulder pads

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.



**SEAM ALLOWANCE:** all seams - 1 cm, on hem of the garment and of sleeve - 4 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

### **Fabric:**

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front– cut 2
5. Button-stand facing – cut 2
6. Upper sleeve –cut 2
7. Lower sleeve – cut 2
8. Back neck facing – cut 1
9. Collar-stand – cut 2
10. Collar –cut 2
11. Pocket – cut 2

Lining:

1. Center back – cut 2
2. Side back - cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Pocket –cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

Interfacing: button-stand facing, back neck facing, collar, collar-stand, side front, center front, upper center back, armhole section, center back hem seam allowance, armhole of side back, side back hem seam allowance, lower sleeve hem seam allowance, upper sleeve hem seam allowance

**INSTRUCTIONS:**

1. Apply interfacing to listed parts.
2. Mark and sew darts on center back, press toward center. Mark and sew darts on front, press toward hem.
3. Sew pocket bag lining onto right side of center front according to notches, sew pocket bag from main fabric onto side front, right sides together. Turn seam back and topstitch onto pocket bag.
4. Sew side backs to center backs. Clip into curves and press seams open. Sew center back seam. Press seam toward left. Sew side fronts to center fronts, sewing pocket bags at the same time. Clip into curves and press seams open above and below pocket bag.
5. Pin collar right sides together, and sew ends and outer edge. Trim, turn right side out. Sew collar-stand right sides together, inserting collar between them, starting and ending the stitch exactly near collar-stand connecting line. Turn right side out, press ready collar. Sew decorative stitch or topstitch on collar at 0.2 cm from the edge.
6. Pin button-stand facing onto front, right sides together, sew along button-stand line from hem up to front center line. Sew lower edges of button-stand facings to center front exactly on marked hem-line. Trim seams of upper and lower corners of button-stand. Turn button stands right side out, straighten seams.
7. Sew shoulder and side seams of jacket. Press shoulder and side seams apart.
8. Sew and press apart shoulder edges of button-stand facing and back neck facing. Sew lower collar into the neckline, and upper collar into the button-stand facings and back neck facing. Sew decorative stitch or topstitch along button-stand at 0.2 cm from the edge.
9. Sew and press apart elbow sleeve seam.
10. Sew and press apart front sleeve seam.
11. Make a gathering stitch along sleeve caps for ease. Sew sleeves into armholes according to notches and adjust ease. Sew in shoulder pads.
12. Sew details of lining, leaving a slit in right sleeve for turning. Press lining.
13. Sew lining to inner edges of button-stand facings and back neck facing. Press allowances of collar connecting seams apart and attach them close to seams.
14. Sew lining to hem of jacket and hem of sleeve. Turn jacket out through the slit in sleeve. Sew slit in sleeve closed.

15. Topstitch garment hem and sleeve hem at 3 cm from the edge without catching the lining. Topstitch front onto button-stand facing, at 5 cm from the edge.
16. Make buttonholes on right front, sew buttons on left front.

**TECHNICAL DRAWING:**

