

## Sewing Pattern — Dress 4290

Recommendations on fabric: natural or mixed knit fabric of low or medium stretchiness

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowances: hem and lower edge of sleeve — 1.5 cm, lower edge of yoke, top edges of central and side front parts — 1.5 cm, along neckline -1.5 cm, all other seams - 1 cm

**Attention!** First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### Advice:

Knitted fabric details are sewn together with special elastic or narrow zig-zag stitch. When serging cut seam allowances to 0.6 – 0.8 cm. Seam allowance on turnup is stitched with twin needles to save stretchiness.

### **CUTTING:**

#### Fabric:

1. Central back part – 2 details
2. Side back part – 2 details
3. Central front part – 1 detail
4. Side front part – 2 details
5. Yoke — 1 detail
6. Sleeve — 2 details

### **INSTRUCTIONS:**

1. Sew princess edge of front part. Serge and press the seam towards center. Slash away seam allowance on section between round markers. Serge this section, fold onto wrong side and topstitch. Stitch yoke to front part. Serge seam allowance, serging free edge of the yoke at the same time and press onto yoke. Topstitch seam allowance and open edge of the yoke onto the yoke at 0.5 cm off the connecting seam.

2. Sew princess edge of back part. Serge and press seam allowance towards center. Sew and serge center edge of back part. Press seam allowance onto left side.
3. Sew side and shoulder edges. Serge and press seam allowances towards back part.
4. Serge seam allowances of neckline. Turn seam allowances inside and topstitch.
5. Sew sleeve seam. Serge and press onto back part. Sew the sleeve into armhole, leveling notches.
6. Serge hem of garment, lower edge of sleeve. Fold to the wrong side, press and topstitch.

**TECHNICAL DRAWING:**

