

Sewing Pattern — Bag 3019

Recommendations on fabric: stiff natural/mixed fabric (cotton velvet or fabric suitable for suits)

You will also need: fusing, lining, thin strengthener, decorative cord, 1 zipper for inner pocket.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams. 0.5 cm for the handle.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Upper part – 1 piece
2. Center part – 2 pieces
3. Bottom – 1 piece
4. Handle – 2 pieces

Lining:

1. Center part – 2 pieces
2. Bottom – 1 piece
3. Large sacking – 1 piece
4. Small sacking – 1 piece

Strengthener:

1. Center part – 2 pieces
2. Bottom – 1 piece

Fusing: upper/center parts and bottom.

INSTRUCTIONS:

1. Apply the fusing to wrong side of upper/center parts and bottom. Quilt the bottom and center part with the strengthener.

2. Set loops into upper part as marked.
3. Stitch upper part's side edges as a ring. Fold upper part along the center right side out and make 3 parallel stitches as marked, to make coulisses.
4. Stitch center parts to the bottom slashing corners.
5. Mark inner pocket at lining center part. Strengthen zipper place with the fusing. Cut a slit along the pocket entrance, make slashes at 1-1.5 cm from pocket end. Fold seam allowances into left side. Lay the zipper under pocket entrance edge with its teeth visible. Topstitch pocket entrance at 0.2 cm front the edge. Stitch large sacking to zipper upper braid, stitch small sacking to lower braid. Stitch lining edges.
6. Stitch lining bottom to lining center part slashing corners. Leave a hole in one of seams for turning the bag right side out.
7. Fold the handle along the center right side out and fold long edges under. Make a stitch at 0.1 cm from the edge.
8. Stitch handles to the bottom as marked.
9. Lay the bag and bag lining right sides together inserting upper part. Adjust edges and stitch details together.
10. Turn the bag right side out. Stitch the hole. Cut the cord into two parts; set one cord into upper coulisse, set another one into lower coulisse. Gather cords.

TECHNICAL DRAWING:

