

## Sewing Pattern — Hoodie 4341

Recommendations on fabric: natural or mixed heavy, medium stretch knit fabric

You will also need: zipper (length is shown on front pattern piece).

Seam allowances: all seams - 0.8 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



### **CUTTING:**

**Advice:** Knit fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hem is stitched with twin needles to save stretchiness. Pieces can also be sewn together with 3 or 4 – thread serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

### **Main fabric:**

1. Back – cut 1
2. Right front — cut 1
3. Left front — cut 1
4. Lower front — cut 1
5. Sleeve — cut 2
6. Lower part (band) -cut 1 on fold
7. Cuff — cut 2
8. Front left of hood — cut 1, cut 1 for inner hood
9. Front right of hood — cut 1, cut 1 for inner hood
10. Back of hood — cut 2, cut 2 for inner hood

## **INSTRUCTIONS:**

1. Sew shoulder seams. Serge seam and press towards back.
2. Sew outer back part of hood to outer front and outer right parts of hood. Serge seams. Make another hood for inside and serge lower edge. Sew the outer hood into the neckline. Serge seam and press toward hood.
3. Serge edges for zipper. Sew in zipper along fronts and hood edge. Sew inner hood to outer hood, right sides together, along upper edge. Clip into curves. Turn inner part of hood to the inside. Fold under and slipstitch inner center front seam allowance to zipper tape. Topstitch lower seam allowance of inner hood into neckline connecting seam. Topstitch upper edge of hood and along zipper.
4. Sew lower front to upper parts. Serge seam and press it downwards. Topstitch.
5. Sew sleeve into open armhole, matching marks, serge seam.
6. Sew side seam and seam of sleeve at the same time. Serge seam.
7. Sew lower part (band) into ring. Press seam allowance apart. Fold in half, wrong sides together, and sew to lower edge, slightly stretching lower part. Serge seam and press upwards. Topstitch at 0.5 cm from the seam.
8. Sew cuff into ring. Press seam allowance apart. Fold cuff in half, wrong sides together, and sew to lower edge of sleeve, slightly stretching cuff. Serge seam and press toward sleeve. Topstitch at 0.5 cm from the seam.

## **TECHNICAL DRAWING:**

