

## Sewing Pattern — Coat 7208

Recommendations on fabric: fabric suitable for coats  
(gabardine, cashmere)

You will also need: fusible interfacing; lining; shoulder pads; 6 buttons

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams -1 cm; hem of the garment - 2.5 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

#### Fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Lower front – cut 2
6. Lower back – cut 1 on fold
7. Sleeve – cut 2
8. Cuff – cut 2
9. Back neckline facing – cut 1
10. Front band facing – cut 2
11. Collar stand – cut 2

#### Lining:

1. Center back – cut 2
2. Center front – cut 2
3. Lower front – cut 2
4. Side back – cut 2
5. Side front – cut 2
6. Lower back – cut 1 on fold



## 7. Sleeve – cut 2

### Fusible interfacing:

1. Center front – cut 2
2. Front band facing – cut 2
3. Back neckline facing – cut 1
4. Outer collar stand – cut 1
5. Cuff – cut 2

Also ally interfacing to back armhole sections, hem of the garment and cuffs.

### **INSTRUCTIONS:**

1. Apply interfacing to listed pieces.
2. Sew center and side backs, press seam apart. Sew middle back edge, press seam apart. Make a counter pleat on lower back and fasten on upper edge. Sew upper and lower backs, press seam apart.
3. Sew center and side fronts, press seam apart. Make a counter pleat on lower front and fasten on upper edge. Sew upper and lower fronts, press seam apart.
4. Sew side and shoulder edges. Press seam apart.
5. Sew cuff into ring. Press seam apart. Fold cuff in half lengthwise. Sew sleeve seam. Press seam apart. Make a gathering stitch on lower edge of sleeve for ease. Stitch outer cuff to sleeve. Press seam apart. Make a gathering stitch along sleeve cap for ease (in case you have thick fabric, make free small pleats). Sew sleeve into armhole. Sew in shoulder pads.
6. Sew shoulder seams of front band facings and facings. Press seam apart. Sew inner collar stand into the neckline. Press seam apart.
7. Cut a strap of 6 cm long and 3 cm wide. Serge one long side. Press unserged edge toward center and close it with serged edge. Make two parallel fixing stitches from right side. Sew outer collar stand into the neckline, inserting the strap.
8. Press hem. Place front band facing and front right sides together. Stitch lower edge of front band facing to hem turnup. Press seam upwards. Pin front band facing to garment and stitch on front band facing and collar stand. Turn front bands and collar stand right side out, straighten seams. Sew together allowances of neckline and facings.
9. Sew seams on lining pieces, leaving an opening in left side seam for turn-out. Sew in sleeve. Stitch lining to front band facings and and facing.
10. Stitch lining to cuff connecting seam, press seam allowance upwards. Fix together seam allowances of cuff. Stitch lining to hem of the garment. Turn coat out through the opening. Sew the opening closed.
11. Topstitch upper edge of strap collar stand. Make buttonholes and sew buttons.

**TECHNICAL DRAWING:**

