

## Sewing Pattern — Dress 4396

Recommendations on fabric: natural or mixed dress fabric of 2 colors.

You will also need: dress zipper, 1 button.

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: on hem of blouse and hem of sleeves – 2.0 cm; all other seams - 1 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.

### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

#### Fabric 1:

1. Central back - cut 2
2. Side back — cut 2
3. Side front — cut 2
4. Sleeve — cut 2
5. Collar – cut 2
6. Drop cut facing – cut 1

#### Fabric 2:

1. Central front - cut 1 on fold

#### Fusible interfacing:

1. Collar – cut 1
2. Drop cut facing – cut 1



## **INSTRUCTIONS:**

1. Apply fusible interfacing to listed pieces.
2. Sew and serge middle edge of back. Press seam allowances to left. Sew central and side backs. Serge seam allowances and press them toward center.
3. Serge lower edge of drop cut facing. Place facing onto central front and stitch drop cut edge. Cut vertically seam allowance of drop "entrance". Trim seam allowances, turn to wrong side and press. Fasten facing to central part on central / side fronts edges. Sew central and side fronts. Serge seam allowances and press them toward center.
4. Sew shoulder edges, serge and press seams to back.
5. Sew right side edge. Serge seam and press it to back. Serge left side edges separately on each detail. Sew left side edge from armhole to first notch and from second notch down to hem. Press seam allowances apart, pressing the opening. Sew in zipper.
6. Sew hang loop. Place collars right sides together and stitch upper edge inserting the loop. Trim seam allowances, turn right side out and press. Sew outer collar into neckline. Turn under allowance of inner collar and topstitch into outer collar connecting seam.
7. Sew sleeve edge. Press and serge seam allowance. Sew sleeves into armholes, matching notches. Press and serge seam allowances.
8. Serge hem of garment and hem of sleeves. Turn to wrong side, press and topstitch. Sew a button on stand collar.

## **TECHNICAL DRAWING:**

