

Sewing Pattern — Dress 4399

Recommendations on fabric: natural or mixed dress fabric.

You will also need: dress zipper, bias tape (approx. length is shown on left front pattern piece).

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: on hem of blouse and hem of sleeves – 2.0 cm; all other seams - 1 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Fabric 1:

1. Central back - cut 2
2. Side back — cut 2
3. Side front — cut 2
4. Central front – cut 1
5. Left front – cut 1
6. Sleeve – cut 2

INSTRUCTIONS:

1. Serge separately middle edges of back. Sew middle edge from zipper mark down to hem. Press apart the seam. Sew in zipper. Sew side and central backs. Serge the seam and press toward center.
2. Make and fasten pleats on central front. Darts are directed downwards.
3. Sew shoulder edges. Serge seams and press to ward back.

4. Serge lower edge of left front. Cut (or take ready) a bias tape of 4 cm wide, length is shown on pattern piece. Fold bias tape in half lengthwise wrong side out and press. Place bias tape onto neckline from the right side and stitch. Clip seam allowances. Turn bias tape to wrong side and topstitch along the fold onto main detail. Press the seam. Lay central front onto left front and fasten on connecting seams. Sew central and left fronts. Serge seams and press toward side edges.
5. Sew side edges. Serge seams and press toward back.
6. Serge lower edge of sleeves. Turn seam allowances to wrong side and topstitch. Sew sleeves into armholes, matching notches. Press and serge seam allowances. Cut (or take ready) a bias tape of 4 cm wide, length is equal to the length of armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Lay bias tape on armhole edge from the right side and stitch. Clip seams. Turn bias tape to wrong side and topstitch along the fold onto main detail. Press the seam.
7. Serge hem of dress. Turn to wrong side, press and topstitch.

TECHNICAL DRAWING:

