

## Sewing Pattern — Dress 4115

Recommendations on fabric: light-weight fabrics suitable for dresses

You will also need: invisible zipper; fusible interfacing; 6 buttons; decorative ribbon for the belt - 6 cm wide

**If the pattern has a double line around it, the seam allowances are included.**

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: on hem - 1.2 cm, other seams - 1.0 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

### **Fabric:**

1. Center back bodice - cut 2
2. Side back bodice - cut 2
3. Back inset- cut 1
4. Center back skirt - cut 2
5. Side back skirt - cut 2
6. Center front bodice - cut 2
7. Side front bodice – cut 2
8. Front inset - cut 1
9. Center front skirt - cut 1
10. Side front skirt – cut 2
11. Button placket - cut 2

12. Collar - cut 2
13. Collar-stand - cut 2
14. Sleeve - cut 2
15. Cuff - cut 2

Interfacing:

1. Button placket - cut 2
2. Collar - cut 1
3. Collar-stand - cut 1
4. Cuff - cut 2

**INSTRUCTIONS:**

1. Apply interfacing to listed pieces.
2. Sew side back bodice to center back bodice. Serge and press seam toward center. Topstitch at 0.5 cm from the seam. Sew center back seam, serge and press toward left.
3. Sew side front bodice to center front bodice. Serge and press seam toward center. Topstitch at 0.5 cm from the seam.
4. Press the button plackets in half lengthwise, wrong sides together. Sew outer side of the plackets to fronts, press seam toward placket. Turn inner edge of the placket under 1 cm, and topstitch into connecting seam. Make buttonholes on right placket. Place right front placket over left, and sew along the lower edge.
5. Sew shoulder seams, serge and press seam toward back.
6. Pin collar right sides together. Sew ends and outer edge of collar. Clip into curves. Turn collar right side out, straighten, and press. Pin collar-stand, right sides together, inserting ready collar between them, match notches and sew, include ends of the collar-stand at the same time. Start and finish the stitch exactly near marked line of the collar-stand seam allowance. Turn right side out and press.
7. Sew outer collar-stand with collar to neckline, right sides together, turn seam allowance of inner collar-stand under and topstitch into outer collar-stand seam. Topstitch along the collar and collar-stand at 0.5 cm.
8. Sew back inset to back bodice, serge and press seam onto inset. Topstitch at 0.5 cm from the seam. Sew front inset to front bodice, serge and press seam onto inset. Topstitch at 0.5 cm from the seam.
9. Sew side back skirt to center back skirt, serge and press seam toward center. Sew center back seam. Serge and press seam toward left. Sew side front skirt to center front skirt, serge seam and press toward center.
10. Sew back skirt to back inset, serge and press seam onto inset. Topstitch at 0.5 cm from the seam. Sew front skirt to front inset, serge and press seam onto inset. Topstitch at 0.5 cm from the seam.
11. Serge left side edges of garment separately. Sew seam from the armhole to top mark and from lower mark to hem. Press apart seam, including the opening for zipper. Sew in zipper. Sew right side seam, serge and press seam toward back.
12. Sew sleeve seam, serge and press. Make a gathering stitch along the sleeve cap and bottom edge of sleeve between marks and gather fullness.
13. Sew cuff into ring, press apart seam allowances. Fold cuff in half lengthwise, wrong sides together and press. Sew outer edge of cuff to sleeve, press seam onto cuff. Turn under seam allowance of inner cuff and topstitch into connecting seam. Topstitch at 0.5 cm from the connecting seam of cuff and along the edge.
14. Sew sleeve into armhole, matching notches and adjusting gathers.
15. Serge lower edge of the garment, press onto wrong side and topstitch.
16. Sew buttons on left placket.

**TECHNICAL DRAWING:**

