

## Sewing Pattern — Dress 4306

<u>Recommendations on fabric:</u> silk fabric suitable for dresses; contrast fabric for decoration.

You will also need: lining, blind zipper, fusing.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

SEAM ALLOWANCE: all seams - 1 cm; on hem of the dress – 2.0 cm; along the slit – 2 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



#### **CUTTING**:

## Fabric:

- 1. Central upper back part 1 detail
- 2. Side upper back part 2 details
- 3. Central lower back part 2 details
- 4. Side lower back part 2 details
- 5. Central upper front part 1 detail
- 6. Side upper front part 2 details
- 7. Central lower front part 1 detail
- 8. Side lower front part 2 details
- 9. Facing of back part 2 details
- 10. Facing of front part 2 details

#### **Decoration fabric:**

- 1. Inset of back part 1 detail
- 2. Inset of front part 1 detail
- 3. Belt 1 detail

#### Lining:

- 1. Central upper back part 1 detail
- 2. Side upper back part 2 details
- 3. Front part 1 detail
- 4. Side upper front part 2 details



#### Fusing:

- 1. Facing of back part 1 detail
- 2. Facing of front part 1 detail

### **INSTRUCTIONS**:

- 1. Apply fusing to details of the facings.
- 2. Sew princess edges on upper details of back part and of front part. Press seam allowances to center of details. Make and fasten pleats on front part according to markers (depths are turned from the center). Sew right side edge, press seam allowances apart. Overstitch details of lining the same way.
- 3. Fold lining with upper part of the dress and overstitch edges of armholes. Slash seam allowances on rounded parts, turn details right side out, press. Fix details along neckline edges.
- 4. Serge center edge of central lower back part separately on each detail. Sew center edge of back part from top edge up to slit marker, press seam allowances apart. Sew princess edges on lower details of back part and of front part. Press seam allowances to the center of back part and of front part and serge.
- 5. Stitch lower back part to the inset, press seam allowances upwards and serge. Stitch lower front part to the inset, press seam allowances upwards and serge. Sew right side edge, press seam onto back part and serge. Stitch top part of the dress to lower, press seam allowances downwards and serge.
- 6. Serge separately left side edges, sew from zipper notch downwards. Press apart the seam. Sew in the zipper. Turn inside the ends of zipper tape near the armhole and undersew.
- 7. Sew shoulder seams of the facings, press seam allowances apart. Fold facings right sides together and overstitch lower edge. Slash seam allowances on rounded parts, turn detail right side out, press. Slash away top seam allowance near the notches, put outer facing to the wrong side of the garment and stitch the facing to neckline. Press seam allowances onto the facing. Slash unsewn edges of the facing on rounded parts, turn inside and topstitch onto each other roundwise, turning the dress back previously. Turn facing onto wrong side and tack to front part and back part with several tacks.
- 8. Serge hem seam allowance of the dress, press onto wrong side and undersew with invisible stitches.
- 9. Fold belt in half lengthwise right sides together and overstitch on long and short sides, leaving a slit. Turn belt right side out, press. Put decorative stitch along the perimeter at 0.2 cm.



# **TECHNICAL DRAWING:**



