

## Sewing Pattern — Blouse 4086

Recommendations on fabric: thin silk or viscose fabrics

You will also need: fusing, 10 buttons.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: on hem of the garment – 2 cm, all other seams – 1cm .

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Main fabric:

1. Back part – 1 detail
2. Panel – 2 details
3. Front part – 2 details
4. Stand-up part of collar — 2 details
6. Sleeve – 2 details
7. Cuff – 2 details

Fusing: cuffs, panels, stand-up part of collar — 1 detail

### **INSTRUCTIONS:**

1. Apply fusing to cuffs, panels and stand-up part of collar.
2. Press panel in half lengthwise wrong sides together. Stitch outer side of panel to front part. Press seam to panel. Turn inner edge of panel inside on 1 cm and topstitch.
3. Sew shoulder and side edges of the blouse. Serge side and shoulder seams. Press side and shoulder seams towards back part.
4. Fold stand-up part of collar details right sides together and overstitch. Start and finish the stitch exactly near the neckline connecting seam. Turn stand-up part of collar and press.
5. Stitch loosely on front part neckline edge by 0, 5 cm off the edge. Gather ruffles, leveling with the section on stand-up part of collar.
6. Sew outer side of stand-up part of collar into the neckline, press seam to stand-up part of collar. Turn inner edge and topstitch into connecting seam. Stitch stand-up part of collar on contour.

7. Fold cuffs right sides together and overstretch side edges, cut seam allowances in corners and turn onto right side. Press cuffs.
8. Cut bias tape 19\*3 cm for piping the sleeve slit. Mark a closure line on sleeve, cut the sleeve on the line. Lay the sleeve on slit line into a straight line and overstretch slit with piping seam with closed cut. Piping width is 0.5 – 0.7 cm. The width of the seam on slit length is 0.5 – 0.7 cm, in top part of slit it is reduced to 0.2 cm. Stitch loosely along the edge of sleeve. Draw hem of sleeve to the length of cuff.
9. Sew, serge and press sleeve seam. Sew in sleeve, gathering slightly on rounded part.
10. Stitch cuff outer side to sleeve hem. Turn seam allowance of cuff inner side and topstitch into connecting seam.
11. Press hem of the garment twice on 1 cm onto wrong side and topstitch.
12. Serge buttonholes on front parts, stand-up part of collar and cuffs and sew buttons.

**TECHNICAL DRAWING:**

