

4701 - Sewing Pattern #4701

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: lining.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Buttonstand – cut 2
4. Sleeve – cut 2
5. Back neck facing – cut 1
6. Belt – cut 1

Lining:

1. Pocket bag – cut 4

INSTRUCTIONS:

1. Sew center back seam, press seam apart, serge.
2. Sew darts on front. Press bulk towards center.
3. Clip into seam allowance on front in the corner near shoulder seam. Sew collar seam, press seam apart. Sew shoulder seams, sewing collar into the neckline at the same time.
4. Sew pocket bags to back and to front. Sew side seams, sewing the pocket bags at the same time, press seams towards back and serge.
5. Sew shoulder seams of buttonstands and facings, clip into corners of seam allowances. Sew collar seam. Sew collar into neckline, press seam apart. Serge outer edge.
6. Pin center front facing to front right sides together and sew collar fall, center front standing and lower edge. Slip stitch together seam allowances along collar seams.
7. Sew sleeve seam, press towards elbow and serge. Sew sleeves into armholes matching notches, serge and press.
8. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch or hem as desired.
9. Fold belt in half lengthwise, right sides together, and sew along long side and one short side. Turn belt right side out, turn seam allowances along unsewn edge under and sew a decorative stitch at 0.7 cm from edge around the belt.

TECHNICAL DRAWING:

