

## 4704 - Sewing Pattern #4704

Recommendations on fabric: natural/mixed fabrics suitable for raincoats.

You will also need: separating zipper; elastic tape; decorative cord.

Seam allowances: all seams 1 cm. Seam allowances along hem, sleeve hem, upper edge of pocket, side edges of pocket facings – 3 cm

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Sleeve – cut 2
4. Back neck facing – cut 1
5. Buttonstand – cut 2
6. Front placket – cut 1

7. Hood – cut 2
8. Center hood – cut 1
9. Hood facing – cut 1
10. Pocket – cut 2
11. Flap – cut 4
12. Pocket facing – cut 2
13. Off-set welt – cut 2

Fusible interfacing:

1. Front placket – cut 1
2. Buttonstand – cut 2
3. Back neck facing – cut 1
4. Flap – cut 2
5. Off-set welt – cut 2

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew front darts, press bulk towards top.
3. Fold off-set welt in half lengthwise right sides together and sew short sides. Trim seam allowances and turn right side out. Pin off-set welt onto front, matching the seam line with lower marking line and topstitch along lower edge. Fold off-set welt towards top and topstitch along two short edges..
3. Press lower seam allowance of pocket facing at 1 cm onto wrong side. Sew the non-pressed edge of pocket facing to pocket along side edges and lower edge. Turn under the upper seam allowance of the pocket twice onto wrong side and topstitch. Pin pockets onto fronts according to markings and topstitch. Pin together flaps right sides together and sew outer edges. Clip into curves, turn flaps right side out, straighten, press. Sew a decorative stitch on flap at 0.5 cm from edge. Serge upper edge. Sew flaps to fronts, fold towards bottom and topstitch.
3. Sew center back seam from neckline to notch. Press seam apart and serge. Topstitch seam allowances of the slit at 0.1 cm from fold.
4. Sew shoulder seams, press seams towards back and serge.
5. Sew in sleeves, serge and press. Sew side seams, sewing the sleeve edges at the same time, press seams towards back and serge. Stretch elastic tape, pin it according to markings at the waist level and topstitch.
6. Sew side hoods to center hood, press seam allowances towards center part and serge. Stretch elastic tape and pin it to front edge of the center part, topstitch.
7. Sew hood into neckline, press towards hood.

8. Pin right side of zipper onto the edge of center front facing and hood (zipper blade should be faced away from the center front edge) and sew. Repeat for left center front facing.

9. Serge inner edge of hood facing. Serge outer edge of center front facings and back neckline facing. Sew hood facing into neckline of center front facings, seam allowances press towards facing.

10. Pin center front facings with facings onto front right sides together and sew around the outer edge of center front facings and hood. Clip into curves, trim away corners. Turn Right Side Out buttonstands onto wrong side, straighten, press.

11. Sew shoulder seams of buttonstands and facings. Press seam apart. Stitch in the ditch the center front facings and the neckline facing into the seam of hood. Press seam. Topstitch hood facing onto self hood.

12. Fold front placket in half lengthwise right sides together and sew corners. Turn right side out and press. Sew decorative stitches along outer fold, along upper and lower edges.. Serge inner edge. Pin placket onto front and topstitch along the marked line. Fold placket so that the closure is covered with it, and sew a decorative stitch along placket.

13. Press hem of garment and press of sleeve onto wrong side at 1 cm, then again at 2 cm and topstitch, making a casing. Thread elastic tape into casing on the sleeve. Thread cord into the casing along hem and slipstitch.

## TECHNICAL DRAWING:

