

Coat - Sewing Pattern #4716

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: lining; shoulder pads; sleeve heads; fusible interfacing; separating zipper.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center upper back – cut 2
2. Side upper back – cut 2
3. Center lower back – cut 2

4. Side lower back – cut 2
5. Center upper front – cut 2
6. Side upper front – cut 2
7. Center lower front – cut 2
8. Side lower front – cut 2
9. Upper sleeve – cut 2
10. Lower sleeve – cut 2
11. Buttonstand – cut 2
12. Back neck facing – cut 1
13. Off-set welt – cut 2
14. Underlay piece – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Front – cut 2
4. Upper sleeve – cut 2
5. Lower sleeve – cut 2
6. Large pocket bag — cut 2
7. Small pocket bag — cut 2

Fusible interfacing:

1. Center upper front — cut 2
2. Center lower front — cut 2
3. Buttonstand — cut 2

4. Back neck facing — cut 1

5. Off-set welt – cut 2

Fusible interfacing is also applied to parts of armholes on back and front, pocket opening, lower edge of garment and hem of sleeve.

INSTRUCTIONS:

1. Apply fusible interfacing.

2. Sew darts on center upper back, press bulk towards center. Sew upper side backs to upper center back. Sew lower side backs to lower center back, press seam apart. Sew upper back to lower back, press seam apart. Sew center back seam, press seam apart.

3. Sew princess seams on upper and lower fronts (= sew side fronts to center fronts), press seam apart. Sew upper front to lower front, press seam apart.

4. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew and serge edges of pocket bags.

5. Pin fronts right sides together and adjust edges, measure the length of center front edges. Sew zipper to center front edge.

6. Sew shoulder and side seams, press seam apart.

7. Sew shoulder seams of buttonstands and facings, press seam apart.

8. Serge seam allowance along hem and press it onto wrong side. Place buttonstand onto front right sides together. Pin together buttonstand and top of garment and sew along the buttonstand edge and along neckline. Sew lower edge of buttonstand to front exactly according to the marked line of hem, stepping back from inner size of buttonstand at 1.5 cm. Turn buttonstands right side out, straighten seams.

9. Sew and press apart elbow sleeve seam. Press seam allowance on lower edge onto wrong side. Sew and press apart front sleeve seam. Sew a line with short stitches along upper edge of sleeve cap. Gather fullness and press gathered ease. Sew sleeves into armholes matching notches and adjusting ease. Sew shoulder pads and sleeve heads to garment.

10. Sew darts and seams on lining, sew in sleeves. Serge, fold inside and topstitch lower edge of lining. Sew lining

to inner edges of buttonstands and to back neckline facing. Sew lining to hem of sleeve.

TECHNICAL DRAWING:

