

Jacket With Decorative Belt - Sewing Pattern #4762

Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; zipper.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Back belt - cut 2
4. Outer belt - cut 1
5. Inner belt - cut 1
6. Upper sleeve - cut 2
7. Lower sleeve - cut 2

8. Center front facing – cut 2

Fusible interfacing: center front facing.

INSTRUCTIONS:

1. Apply fusible interfacing to center front facings (button stands).
2. Sew darts on back, press bulk towards center. Sew darts on front, press bulk towards side seams. Make and baste pleats on fronts.
3. Pin together back belts, right sides together and sew along upper and lower edges. Turn the piece right side out and press. Pin together inner belt and outer belt, right sides together and sew along upper and lower edges. Turn the piece right side out and press. Make pleats as desired on outer belt, and baste them.
4. Serge the inner edge of center front facing. Pin buttonstand (center front facing) onto garment right sides together and sew center front edge and collar edge. Clip seam allowances, turn right side out center front facings onto wrong side, press. Put right front onto left front and baste together along center lines.
5. Pin belt onto front and baste together along left side edge. Pin back belt onto left back and baste together along side and center edge.
6. Sew side seams, press seams towards back and serge. Baste raw edge of the belt to center edge of the right back.
7. Serge separately center back edges. Sew center back seam from notch for zipper to bottom, press seam apart.
8. Clip into seam allowance in corner near shoulder seam and collar. Sew shoulder seams, sewing collar into the neckline at the same time. Serge seams and press towards back. Sew in zipper in the center seam. Topstitch center front facing into the collar seam.
9. Sew elbow seam on sleeve, serge and press. Sew front seam on sleeve, serge and press. Sew sleeves into armholes matching notches.
10. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and finish with hidden stitches.

TECHNICAL DRAWING:

