

4763 - Sewing Pattern #4763

Recommendations on fabric: thick natural/mixed fabric suitable for dresses. Contrasting fabric for decoration.

You will also need: fusible interfacing, zipper, 10 buttons.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 2.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Right front - cut 1
3. Left front - cut 1
4. Front neck facing — cut 1
5. Back neck facing – cut 2
6. Sleeve — cut 2

7. Sleeve facing – cut 2

Decorative fabric:

1. Inset - cut 1
2. Cuff — cut 2

Fusible interfacing:

1. Front neck facing — cut 1
2. Back neck facing – cut 2

INSTRUCTIONS:

1. Apply interfacing to facings.
2. Sew waist darts on back, press bulk towards center. Sew bust dart on right front, press bulk towards top.
3. Serge separately center back edges. Sew center back seam from notch for zipper to bottom. Press seam apart, pressing the slit for zipper at the same time. Sew in zipper.
4. Serge seam allowance of the whole cut placket on right front. Fold inside placket onto wrong side along the marked line and baste. Baste in two steps: first from waist to shoulder and then from waist to hem.
5. Serge side edges and lower edge of inset, seam allowance along hem press onto wrong side and topstitch. Serge seam allowance of the princess seam and wholecut placket on left front. Fold inside placket onto wrong side and baste. Pin left front onto inset (edge of the front is longer than edge of the inset by the width of seam allowance along hem) and topstitch.
6. Put right front onto left front front (edge of the right front is longer than edge of the inset by the width of seam allowance along hem) and topstitch.
7. Sew side and shoulder seams, press seams towards back and serge.
8. Sew shoulder seams of neck facings, serge outer edge. Pin facing to dress right sides together, adjusting neckline edges, and sew. Clip into curves, turn facing under and press. Slipstitch facing to shoulder seams and zipper tape.
9. Sew sleeve seam, serge and press. Sew sleeves into armholes, matching notches. Serge and press.
10. Fold cuff in half lengthwise, right sides together and sew ends, trim away corners. Turn cuff right side out, straighten, press. Sew sleeve facing into a ring, serge outer edge. Pin facing onto sleeve right sides together, insert cuff between pieces, matching mark on cuff with sleeve seam and sew lower edge. Turn facing under,

straighten, press and topstitch.

11. Serge lower edge of garment, press onto wrong side and topstitch.

12. Sew on buttons on front placket and cuff.

TECHNICAL DRAWING:

