

Jacket With Belt - Sewing Pattern #4768

Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; lining; 2 buttons; shoulder pads, sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2

7. Back neck facing – cut 1
8. Center front facing – cut 2
9. Belt – cut 1

Lining:

1. Center back – cut 2
2. Center front – cut 2
3. Side back – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Fusible interfacing: center front, back neck facing, center front facing.

Attention: lining is cut using pattern blocks for self fabric except for the area of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, press bulk towards center. Sew side backs to center back, press seam apart. Sew center back seam, press seam apart.
3. Make and sew pleats on front according to markings, lay out the bulk of pleat flat to both sides and press. Sew side fronts to front, press seam apart.
4. Sew collar seam, press seam apart. Sew shoulder seams, press seams towards back. Clip into seam allowance of shoulder seam on front and sew collar into back neckline, press seam apart.
5. Sew side seams, press seam apart.
6. Sew the elbow seam of the sleeve and press it apart. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches. Sew shoulder pads, sew sleeve heads.
7. Sew collar seam on center front facings, press seam apart. Sew shoulder seams of buttonstands and facings, clipping into seam allowances near corners. Sew collar into neckline facings, press seam apart. Sew seams on lining and sew in sleeves, leaving an opening for turning in front right sleeve seam. Sew lining to buttonstands and facing.
8. Place center front facing onto front right sides together, pin together and sew around center front and collar. Sew lining to lower edge of garment and lower edge of sleeve. Turn jacket right side out. Sew the opening

closed. Slip stitch seam allowances along the seams of inner and outer collars together. Sew the opening in sleeve closed.

9. Make buttonholes on right front, sew on buttons on left front.

10. Fold belt in half lengthwise right sides together and sew, leaving an opening. Trim away corners, turn belt right side out, straighten and press. Sew the opening closed.

TECHNICAL DRAWING:

