

Sewing Pattern — Dress 4065

Recommendations on fabric: fabric suitable for dresses.

You will also need: bias tape in contrasting color (the approximate length is mentioned on the pattern for front part), zipper, 3 buttons, fusing.

If the pattern has double contour, seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance on hem – 2 cm, outer seam allowance of the flounce and of rose – 0 cm, all other seams 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

Main fabric:

1. Central front part – 1 detail
2. Side front part – 2 details
3. Central back part – 2 details
4. Side back part – 2 details
5. Flounce – 2 details
6. Rose – 2 details
7. Back neckline facing – 2 details
8. Front neckline facing – 1 detail
9. Belt — 1 detail

Fusing:

1. Back neckline facing – 2 details
2. Front neckline facing – 1 detail
3. Belt – 1 detail



INSTRUCTIONS:

1. Apply fusing to details using hot iron. For belt rather use thick fusing.
2. Sew relieve seams on back part. Serge and press the seam towards center. Serge central edges of back part. Sew central back seam from zipper marker to hem and press apart. Sew in zipper.
3. Fold details of the flounce wrong sides together and level edges. Overstitch outer edge with bias tape and press. In the same way process upper edge of rose.
4. Stitch flounce to relieve edge of left front part, according to the notches. Fasten upper edge of the flounce to shoulder edge (up to marker). Fold rose in half, leveling short cross edges. Fasten short edges of rose to shoulder edge on top of the flounce, leveling open edge of rose with relieve seam of side front part. Fold loose end of rose into a coil, placing coil between round markers. Sew left relieve edge. Serge and press the seam towards center. Sew right relieve edge of front part. Serge and press the seam towards center.
5. Sew shoulder seams. Serge and press towards back part.
6. Cut bias tape from the main fabric of the length equalling the length of the armhole, width is 4 cm. Press it in half lengthwise wrong sides together, put onto armhole and stitch. Turn the bias tape onto wrong side, slash seam allowances and topstitch along the fold.
7. Sew side seams, serge and press towards back part.
8. Sew shoulder seams of the facings. Press apart the seam. Serge outer edge of the facings. Put facings onto right side of the dress and overstitch the neckline. Slash seam allowances and turn the facing onto wrong side. Fasten the facing to shoulder seams and zipper.
9. Serge hem of garment. Turn onto wrong side, press and undersew with invisible stitches.
10. Fold пояс in half lengthwise right sides together and overstitch long and 1 short sides. Turn belt inside out, straighten corners and press. Sew short side. Make buttonholes and sew on buttons.

TECHNICAL DRAWING:

