

Jacket With Knit Sleeves - Sewing Pattern #4818

Recommendations on fabric: quilted fabrics with polyester padding, suitable for outdoor jackets; knit fabric in the same color.

You will also need: lining; separating zipper; bias tape.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 3 cm. Seam allowance along the lower edge of outer sleeve – 0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold
2. Side back – cut 2

3. Side front – cut 2
4. Front – cut 2
5. Back neck facing – cut 1
6. Center front facing – cut 2
7. Collar -cut 1
8. Front placket – cut 1
9. Sleeve – cut 2

Knit fabric:

1. Outer sleeve – cut 2
2. Cuff – cut 2

Lining:

1. Back lining – cut 1 on fold
2. Front lining – cut 2
3. Sleeve – cut 2
4. Pocket bag – cut 4

INSTRUCTIONS:

1. Sew shoulder seams of side backs and side fronts, press the seam apart. Sew sleeve into armhole, press seam. Sew side seams of side backs and side fronts processing the sleeve seam at the same time, press the seam apart.
2. Sew seam of outer sleeve, press the seam apart. Pin outer sleeve onto side part, wrong side onto right side, baste together along edges.
3. Sew shoulder and side seams on backs and fronts, press the seam apart.
4. Sew pocket bags to side fronts and to front. Stitch the princess seams all around, simultaneously stitching the pocket bags. Press the seam allowances onto the main piece and topstitch at 0.5 – 0.7 cm from seam.
5. Sew the outer collar into neckline. Clip into seam allowances and press apart.
6. Sew shoulder seams of central front facings and facings, press the seam apart. Sew the inner collar into the neckline, clip into seam allowances and press apart.
7. Fold front placket in half lengthwise right sides together and sew corners. Turn right side out and press. Sew decorative stitches along outer fold, along upper and lower edge. Topstitch the left half of the zipper to the placket, aligning the edge of the zipper tape with the raw edge of the placket.
8. Place center front facing onto front right sides together and sew along the center front edge, inserting zipper, sewing the collar at the same time. Start and stop stitching exactly at the marked hem line.

9. Sew cuff into a ring. Fold cuff in half lengthwise and press wrong sides together. Sew cuff to lower edge of sleeve.
10. On the lining pieces, fold the pleat on the front according to the markings, sew side and shoulder seams, leaving an opening in left side seam. Sew in the sleeves.
11. Baste the collar-to-neckline seam allowances together. Sew lining to the central front facings and to facing. Turn garment right side out. Sew lower edge of lining to hem of garment. Sew the lining to the lower edge of the sleeve. Sew the opening closed.
12. Bind the lower edge of the outer sleeve with bias binding.

TECHNICAL DRAWING:

