

## Asymmetrical Jacket - Sewing Pattern #2047

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: decorative fabric; fusible interfacing; lining; thin shoulder pads; 1 snap-fastener.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Front fly piece - cut 2
6. Center front facing — cut 2
7. Back neck facing - cut 1

8. Sleeve - cut 2

Decorative fabric:

1. Cuff - cut 2
2. Front fly piece - cut 2

Lining is cut using the pattern blocks for self fabric, except for the width of back neckline facing.

Lining:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front lining - cut 2
5. Sleeve - cut 2
6. Cuff - cut 2

Fusible interfacing: center front, center front facing, back neck facing.

## **INSTRUCTIONS:**

1. Apply fusible interfacing. Cut a tape from fusible interfacing and apply along edge of back neckline.
2. Pin front fly pieces together, right sides together, and sew outer and lower edges. Trim corner and turn right side out. Press. Pin fly piece onto center front and baste together along princess seam edge and shoulder edge.
3. Sew princess seam on front. Press towards side.
4. Seaside back to center back, press seam apart. Sew center back seam. Press seam apart.
5. Sew shoulder seams of jacket. Press seam apart. Sew side seams of jacket. Press seam apart.
6. Sew sleeve seam. Press Apart seam allowances. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise and sew to lower edge of sleeve.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew and press apart shoulder seams of back neckline facing and buttonstand. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in left elbow seam of sleeve. Sew lining to facing and buttonstands.
9. Pin together jacket and lining right sides together, pin together, matching outer edges. Sew lining to center

front facing and neckline. Sew lining to hem of jacket. Sew lining to hem of sleeve. Turn jacket right side out through the opening. Sew the opening closed.

10. Slipstitch fly piece in place from the wrong side.

11. Install snap fastener on front.

### TECHNICAL DRAWING:

