

Sewing Pattern — Dress 4034

Recommended fabric: silk fabric

You will also need: decoration fabric, fusing; 1 invisible zipper.

If the pattern has a double line around it, the seam allowances are included.

Seam allowance: hem – 3 cm, shoulder and side edges – 1 cm, all other seams - 0 cm.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

(The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Main fabric:

1. Back – Cut 1 on fold
2. Front – Cut 1 on fold

INSTRUCTIONS:

1. Cut a strip of bias tape of 4 cm wide for the keyhole, neckline, and hem of sleeves.
2. Cut a keyhole on front part according to markers. Finish keyhole with bias tape.
3. Sew right shoulder seam, serge and press seam toward back.
4. Make a gathering stitch along neckline of front and gather fullness from shoulder edge up to the notch. Neckline length from shoulder edge to the keyhole is mentioned on front pattern. Finish the neckline with bias tape. Keyhole edges are placed side by side.
5. Sew left shoulder seam, serge and press toward back.
6. Make a gathering stitch along sleeve edge and gather fullness between notches along upper edge. Total length of sleeve hem is mentioned on back pattern. Finish hem of sleeve with bias tape.
7. Sew side seam and sleeve seam at the same time. Clip into curves, press toward back and serge. Tack left shoulder seam and lower edges of sleeves to seam with 2-3 stitches.
8. Press lower edge of the garment first at 1 cm, then again at 2 cm and topstitch.

TECHNICAL DRAWING:

