

Dress With Trimming - Sewing Pattern #2071

Recommendations on fabric: natural / mixed dress fabrics in matching colours.

You will also need: dress zipper, fusible interfacing; lining.

Seam allowances: all seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Upper front - cut 1
3. Lower front - cut 1
4. Sleeve - cut 2
5. Front yoke - cut 2
6. Front side - cut 1

Main fabric 1:

1. Back neck facing - cut 4
2. Front neck facing - cut 2
3. Yoke trimming - cut 2
4. Front decoration - cut 1
5. Pocket trimming - cut 1
6. Hem trimming - cut 1 on fold
7. Cuff - cut 2

Lining:

1. Pocket bag - cut 1

Fusible interfacing:

1. Back neck facing - cut 2
2. Front neck facing - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to neckline facings. Also apply fusible interfacing to the upper part of pocket trimming along the pocket opening.
2. Sew darts on back and front. Press bulk of waist darts towards center, press bulk of bust darts towards top.
3. Sew back neckline facing to back, press seam allowances towards placket.
4. Serge center back edges separately on each piece. Sew center seam from notch for zipper down to hem, press seam apart. Sew in zipper.
5. Sew yoke trimming to front yoke. Serge and press onto yoke. Sew yoke trimming to upper front. Serge and press towards trimming. Sew front neckline facing to facing, press seam allowances towards placket.
6. Sew front trimming to lower edge of upper front. Serge and press towards trimming.
7. Sew trimming to lower front. Serge and press towards trimming. Sew pocket bag to upper edge of front trimming. Fold pocket bag onto wrong side and press. Pin lower front at side and sew together edges of pocket bags. Baste pieces together along upper and side edge.
8. Sew upper front to lower front. Press towards trimming.
9. Sew side and shoulder seams, press seams towards back and serge.
10. Sew shoulder seams on inner facings, press seam apart. Serge outer edge. Pin facings to garment right sides together and sew the neckline. Clip seam allowances, fold facing onto wrong side and stitch-in-the-ditch

along seam of outer facing. Slipstitch facing to zipper tape.

11. Sew sleeve seam, press seams towards back and serge. Sew cuff into a ring. Fold in half lengthwise and press. Sew outer side of cuff to sleeve, fold towards cuff. Fold under the seam allowance of the inner side inside and stitch in the ditch. Sew sleeves into armholes matching notches and adjusting ease, serge and press.

12. Sew hem trimming into ring, press seam apart. Fold trimming in half lengthwise and press. Sew outer edge of trimming to hem of dress. Press towards trimming. Fold under the seam allowance of the inner side inside and stitch in the ditch.

TECHNICAL DRAWING:

