

Sewing Pattern — Dress with Ruffle 4031

<u>Recommended fabric:</u> stretch knit fabric of natural or mixed fibers.

You will also need: fusible interfacing ; 6 buttons.

<u>If the pattern has a double line around it, the seam</u> <u>allowances are included.</u> <u>Seam allowance:</u> hem of the garment – 1.5 cm, outer edge of the ruffle – 0 cm, other seams – 0.8 cm.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

<u>Attention</u>! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

(On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Advice:

Knit fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hem is stitched with twin needles to save stretchiness. Pieces can also be sewn together with 3 or 4 - thread serger. When serging, cut seam allowances to 0.6 - 0.8 cm.

Main fabric:

- 1. Front cut 1 on fold (You will cut slit for button placket later)
- 2. Back cut 2
- 3. Sleeve cut 2
- 4. Cuff cut 2
- 5. Panel cut 2
- 6. Collar cut 2
- 7. Collar-stand cut 2
- 8. Ruffle cut 2



Fusible interfacing:

- 1. Panel (button placket) cut 2
- 2. Collar-stand cut 1 for outer side

INSTRUCTIONS:

1. Apply interfacing to panels and collar-stand outer side.

2. Sew darts on front. Press downwards.

3. Serge outer edge of the ruffle with a roll stitch. Sew a gathering stitch along inner edge and gather ruffles. Baste ruffle to front on each side of centerline for placket. Fold panels in half lengthwise and sew to front on each side of center line. Ruffles will be sandwiched in between. Cut along center line to mark and then clip diagonally into corners on marks. Turn the bottom edge to inside and slip-stitch in place. Finish or serge seam allowance of the panel, of the ruffle and of

front part simultaneously and press toward inside. Topstitch on right side of the right panel at 0. 1 cm off the seam. Turn under bottom edge of right panel; align directly over left panel, and topstitch with two rows.

4. Sew center back seam. Serge and press seam toward left. Sew shoulder seams. Serge and press towards back.

5. Sew side seams. Serge and press towards back.

6. Pin outer collar to inner collar, right sides together. Sew ends and outer edge of collar. Trim seams. Turn collar out, straighten and press. Place collar-stands right sides together, insert finished collar between them, match notches and sew, include collar-stand ends at the same time. Start and finish the seam exactly at marked line of collar-stand connecting seam. Turn finished collar out and press. Sew outer collar-stand with the collar into the neckline; turn under edge of inside collar-stand and stitch in-the-ditch of outer collar-stand connecting seam. Topstitch collar and collar-stand.

7. Sew a gathering stitch on top edge of sleeve between round markers and gather. Sew sleeve seam. Serge. Sew cuff into ring. Turn, fold in half lengthwise and sew to sleeve. Sew sleeves into armholes, matching marks, an adjusting fullness of gathers between markers. Serge and press. 8. Serge hem of garment. Turn under, press, and topstitch.

9. Mark and make buttonholes on right panel, sew buttons on left one.



TECHNICAL DRAWING:

