

## Dress With One-Piece Facing - Sewing Pattern #2146

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; 6 buttons; decorative buckle.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Center front facing - cut 2
4. Collar - cut 2
5. Cuff - cut 2
6. Back neck facing - cut 1
7. Belt - cut 1

Fusible interfacing:

1. Center front facing - cut 2
2. Collar - cut 1
3. Back neck facing - cut 1

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew side and shoulder seams, press seams towards back and serge.
3. Pin collars together, right sides together, and sew collar ends and collar fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, clip into seam allowance near notch. Turn the collar right side out, straighten and press.
4. Sew shoulder edges of center front facings and back neckline facing, press seam apart. Serge outer edge.
5. Place center front facing onto front right sides together, pin together and sew lower corner, along the center front edge and the lapel edge. Sew upwards up to the notch marking the end of collar seam. Trim away corners. Turn buttonstnds (center front edges) right side out, straighten seams.
6. Sew lower collar into neckline of Shell, sew upper collar into neckline of facings of the back neckline and center front. Press apart seam allowances of collars and baste together close to seam.
7. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise right side out. Sew cuff to wrong side of sleeve, serge. Fold cuff to right side.
8. Press lower edge of garment onto wrong side at 1 cm, then again at 2 cm and topstitch.
9. Make buttonholes on right front, sew on buttons on left front. Sew on decorative buttons on right front.
10. Fold belt in half lengthwise right sides together and sew along longer and one shorter sides. Turn belt right side out, straighten, press. Serge the shorter side. Sew a decorative stitch around the contour at 0.1 cm. Thread in and fix buckle on the serged side of the belt.

## **TECHNICAL DRAWING:**

