

Coat With Hood - Sewing Pattern #2191

Recommendations on fabric: natural/mixed fabrics suitable for coats.

You will also need: fusible interfacing; lining; shoulder pads; 1 button; 2 inner buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem – 4 cm. Outer edge of hood – 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Hood - cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Upper sleeve – cut 2



7. Lower sleeve - cut 2
8. Cuff - cut 4
9. Lower front - cut 2
10. Lower back - cut 1

Fusible interfacing:

1. Center front facing - cut 2
2. Back neck facing - cut 1
3. Cuff - cut 2

Lining:

1. Back - cut 2
2. Front - cut 2
3. Upper sleeve - cut 2
4. Lower sleeve - cut 2
5. Hood - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the outer seam allowance of the hood.
2. Sew darts on back, press bulk towards center. Sew and press apart center back seam. Sew lower back to garment. Press seam allowance towards top and topstitch at 0.5 cm from seam.
3. Sew darts on front. Press bulk towards top. Sew lower front. Press seam allowance towards top and topstitch at 0.5 cm from seam.
4. Sew shoulder edges of coat and press apart.
5. Sew hood seam. Press seam apart. Sew the seam on the hood lining. Press towards left. Make and baste pleats on hood and on lining. Direct the bulk towards the shoulder edge. Pin hood to lining right sides together and sew the outer edge. Press towards the lining. Sew a fixing stitch along the outer edge of the hood at 1 cm from the edge. Sew the hood into the coat's neckline.
6. Sew and press apart shoulder seams of back neckline facing and buttonstand.
7. Make inner button holes on the center front facing. Place center front facing onto front right sides together, pin together and sew along the center front edge, along neckline and lower corner.
8. Sew elbow seam on sleeve. Press seam apart. Sew front seam on sleeve. Press seam apart. Sew cuff into a ring, from upper edge to the mark for slit. Clip into seam allowance near the notch and press apart. Pin together cuffs pairwise right sides together and sew slit edge and lower edge. Trim away corners, turn right side out and press. Sew upper cuff to sleeve, press seam apart. Sew sleeves into armholes. Press seam.

9. Sew lining, leaving an opening in left elbow seam. Sew lining to back neckline facing, to center front facing and to hem of coat. Sew lining to hem of sleeve, press seam allowance towards top. Baste seam allowances on cuff together. Turn coat right side out through the opening. Sew the opening closed.

10. Make the outer button hole and sew on button. Sew on inner buttons.

TECHNICAL DRAWING:

