

Blouse With Ties On Cuffs - Sewing Pattern #2193

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, 3 buttons.

Seam allowances: seam allowance for hem of garment — 2.0 cm, other seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front — cut 2
3. Sleeve — cut 2
4. Cuff — cut 4
5. Center front facing — cut 2
6. Back neck facing - cut 1

Fusible interfacing:

1. Center front facing — cut 2
2. Back neck facing - cut 1
3. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew waist tucks on fronts and on backs.
3. Sew center back seam, press towards left and serge.
4. Sew side and shoulder seams, press seams towards back and serge.
5. Sew and press apart shoulder seams of back neckline facing and buttonstand. Serge outer edge.
6. Place center front facing onto front right sides together, pin together and sew lower corner, along the center front edge and neckline. Turn buttonstands (center front edges) right side out, straighten seams.
7. Cut slit on sleeve along the marked line. Cut bias tape from main fabric (or take ready), its width should equal 4 cm and length should equal two lengths of slit +4 cm. Fold bias tape in half lengthwise and press. Press outer seam allowances towards center. Sew bias tape to slit of sleeve (pin bias tape to slit edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line).
8. Sew sleeve seam, press seams towards back and serge. Sew sleeves into armholes, matching notches. Serge and press.
9. Pin cuffs together, right sides together, and sew lower edge and upper edge from corner up to the mark. Trim away corners, clip into seam allowance near notch. Turn cuff right side out, straighten, press. Sew a gathering stitch along lower edge of sleeve and gather fullness. Sew outer side of cuff to lower edge of sleeve. Fold inside inner side of cuff inside and stitch in the ditch.
10. Serge lower edge of garment, press onto wrong side and topstitch.
11. Make buttonholes on right front, sew on buttons on left front.

TECHNICAL DRAWING:

