

Outdoor Jacket - Sewing Pattern #2224

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 6 buttons; 1 inner button; shoulder pads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Upper collar - cut 1
6. Lower collar - cut 1
7. Upper sleeve - cut 2

8. Lower sleeve – cut 2
9. Cuff – cut 2
10. Back neck facing – cut 1
11. Center front facing – cut 2
12. Off-set welt – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Pocket bag – cut 4

Attention: Lining for back and front is cut using pattern blocks for main fabric except for back neckline facing and buttonstands accordingly..

Fusible interfacing:

1. Center front – cut 2
2. Center front facing — cut 2
3. Upper collar – cut 1
4. Back neck facing — cut 1
5. Off-set welt – cut 2
6. Cuff – cut 2

Also apply fusible interfacing to sewing allowances of back armhole, lower edge of garment and seam allowance along the pocket opening.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, press bulk towards center. Sew side backs to center back, press seam apart. Sew center back seam, press seam apart.
3. Sew darts on center front, press bulk towards top. Sew side fronts to front, press seam apart.
4. Mark the position of pocket on the Front with two parallel stitch lines. Fold off-set welt in half lengthwise right sides together and sew side edges. Turn the off-set welt right side out and press. Sew a decorative stitch around the contour at 1 cm from the edge. Mark the line on the off-set welt, that shows its width when ready. Topstitch pocket bag onto the inner side of off-set welt, adjusting the pieces by their center. Place the off-set welt on the right side of the front, right side down, to the marking line. Sew off-set welt. Sew the second pocket

bag to the other pocket marking line. Slash a pocket opening between the marked lines, making slashed cuts towards the corners of the marked pocket. Turn the pocket pieces onto the wrong side. Straighten seam allowances and press. Sew together edges of pocket bags, fixing corners of pocket. Topstitch off-set welt onto front along the shorter edges.

5. Sew the shoulder and the side edges of garment, press seam apart.

6. Pin upper collar to lower collar and sew corners and fall. Start and stop sewing exactly at the marked line of the seam between collar and garment. Clip into curves, clip into seam allowance near notch. Turn the collar right side out, straighten and press.

7. Sew shoulder edges of center front facings and back neckline facing, press seam apart.

8. Place center front facing onto front right sides together, pin together and sew along center front and lapel. Sew upwards up to the notch marking the end of collar seam. Trim away corners. Topstitch seam allowance along center front edge onto center front facing along the closure, and onto front along the part, which is folded away. Place stitch line at 0,2 cm from seam. Turn buttonstands (center front edges) right side out, straighten seams.

9. Sew lower collar into neckline of Shell, sew upper collar into neckline of facings of the back neckline and center front. Press seam allowances of collar apart and baste together close to the seam.

10. Sew and press apart front sleeve seam. Fold cuff in half lengthwise and press, right side out. Fold the cuff apart and sew the outer side of the cuff to the lower edge of sleeve, press towards cuff. Sew elbow seam on the sleeve, sewing the cuff at the same time. Sew sleeve into armhole. Sew on shoulder pads.

11. Sew seams on lining, leaving an opening in left side seam for turning. Sew lining to buttonstands and facing. Sew lower corner center front facings, trim corners. Mark and press onto wrong side lower edge of garment. Sew lining to lower edge of garment. Sew sleeves from lining to inner cuff. Turn the garment right side out through the opening and sew the opening closed.

12. Make buttonholes on right front. On left front sew on buttons. Sew decorative buttons on right front. Make the inner button hole on left front, sew on hidden button.

TECHNICAL DRAWING:

