

Coat With Slanted Front Edge - Sewing Pattern #2227

Recommendations on fabric: natural/mixed fabrics suitable for coats.

You will also need: fusible interfacing; lining; shoulder pads, sleeve heads, 4 buttons, 1 inner button.

Seam allowances: all seams 1 cm. Seam allowance for hem of coat and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Collar - cut 2
6. Upper sleeve - cut 2

7. Lower sleeve - cut 2
8. Back neck facing - cut 1
9. Center front facing - cut 2

Lining:

1. Center back - cut 2
2. Side back - cut 2
3. Front lining - cut 2
4. Upper sleeve - cut 2
5. Lower sleeve - cut 2
6. Pocket bag - cut 4

Fusible interfacing:

1. Center front - cut 2
2. Back neck facing - cut 1
3. Center front facing - cut 2
4. Collar - cut 1

Attention: Back lining is cut using the pattern blocks for self fabric, except for the width of back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to seam allowances along hem of garment and hem of sleeve. Apply fusible interfacing to pocket opening area.
2. Sew darts on back, press bulk towards center. Sew side backs to center back, press seam apart. Sew center back seam, press seam apart.
3. Sew pocket bags to center front and to side front, press towards pocket bag. Sew side fronts to front, sewing the pocket bags at the same time. Press seam apart, clipping into corner on side front. Press pocket bags towards center.
4. Sew side and shoulder edges of the coat and press it apart.
5. Sew lower collar into neckline. Press seam apart.
6. Sew side seams of back neckline facing and buttonstands, press seam apart. Sew upper collar into neckline. Press seam apart. Pin facings and center front facings to front right sides together and sew buttonstand, collar fall and lower corner. Trim away corners, clip into curves. Fold center front facings (buttonstands) onto right side, straighten seams, press.
7. Sew the elbow seam of the sleeve and press it apart. Press hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap. Sew shoulder pads, sew

sleeve heads.

8. Sew seams on lining and sew in sleeves, leaving an opening in left front sleeve seam. Sew lining to inner edges of center front facings (button stands) and to facing. Press lower edge of garment onto wrong side. Sew lining to hem of garment and hem of sleeve. Turn jacket right side out through the opening. Sew the opening closed.

9. Make buttonholes on right front, sew on buttons on the left one. On left front make buttonholes, from the wrong side of right front sew on hidden button.

TECHNICAL DRAWING:

