

Asymmetrical Dress With One-Piece Collar - Sewing Pattern #2325

Recommendations on fabric: thin natural/mixed suiting fabrics.

You will also need: fusible interfacing; 4 buttons; 1 inner button.

Seam allowances: Seam allowance for hem of garment and hem of sleeve - 2 cm. Other seams - 1.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Right front - cut 1
3. Left front - cut 1
4. Sleeve - cut 2
5. Right center front facing - cut 1
6. Left center front facing - cut 1

7. Back neck facing – cut 1

Fusible interfacing:

1. Right center front facing – cut 1
2. Left center front facing – cut 1
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back and front. Press bulk of waist darts towards center, press bulk of bust darts towards top.
3. Sew center back seam, press towards left and serge.
4. Serge outer edge of buttonstand. Pin center front facing onto front and sew the edge of lapel and center front edge from the shoulder seam down to hem. Clip into seam allowances near the shoulder seam, turn center front facing onto wrong side, straighten, press.
5. Serge outer edge of back neckline facing. Pin neckline facing onto Back and sew neckline exactly up to the marked line of shoulder seam. Clip seam allowances, fold facing onto wrong side and press.
6. Sew shoulder seams, inserting the Front between the Back and the Facing press seams towards back and serge. Slipstitch facing to center back seam.
7. Sew side seams, press seams towards back and serge.
8. Sew sleeve seam, press towards back and serge. Sew sleeves into armholes, serge and press.
9. Serge hem of garment and hem of sleeve, press onto wrong side and topstitch.
10. Make buttonholes on right front, sew on buttons on the left one. Make button loop and sew on inner button.

TECHNICAL DRAWING:

