

Boho Dress - Sewing Pattern #2335

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: dress zipper.

Seam allowances: Seam allowance for hem of garment and hem of sleeve - 2 cm; other seams - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper back - cut 2
2. Upper front - cut 1 on fold
3. Lower back - cut 2
4. Lower front - cut 2
5. Collar — cut 2
6. Sleeve - cut 2
7. Front facing - cut 1 on fold

8. Back facing - cut 2

INSTRUCTIONS:

1. Sew side and shoulder seams of upper parts. Serge seams and press towards back.
2. Sew side edges of back facings and front facings. Press seam apart.
3. Sew side seams of lower parts. Serge seams and press towards back. Sew a gathering stitch along the upper edges of lower backs and lower fronts and gather fullness. Pin facings onto the lower parts of the dress, right side down, and sew along the upper edge. Serge.
4. Pin facing to upper part of the dress, right sides together, and sew lower and upper parts of dress.. Clip into curves, trim away corners. Straighten the facing and press lower edge. Sew a stitch line along the upper edge of the facing, from the right side, to fix the edge.
5. Serge separately center back edges. Sew center back seam from neckline up to notch zippers and from notch for zipper to bottom. Press seam apart. Sew in zipper.
6. Sew collar seam. Press seam apart. Sew outer edge of collar into neckline, press seam allowances towards collar. Collar seam is next to left shoulder seam. Fold the seam allowance of the inner side onto the wrong side and press and stitch in the ditch into the seam of the outer side, matching notches.
7. Sew sleeve seams, press towards back and serge. Sew sleeves into armholes, serge and press.
8. Fold under hem of dress and hem of sleeve two times at 1 cm and topstitch.

TECHNICAL DRAWING:

