

## Blouse With Ties On Sleeves - Sewing Pattern #2360

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, 6 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 2 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## CUTTING:

### Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Sleeve - cut 2
4. Cuff - cut 2
5. Center front facing - cut 2
6. Back neck facing - cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew waist darts on backs, press bulk towards center. Sew center back seam, press towards left and serge.
3. Sew vertical darts on Fronts, press towards center and serge. Sew waist darts on fronts, press bulk towards center.
4. Sew side and shoulder seams, press seams towards back and serge.
5. Sew shoulder edges of center front facings and back neckline facing, press seam apart. Serge outer edge. Pin center front facings onto shell right sides together and sew center front edges, front neckline and back neckline. Clip into curves, trim away corners, fold center front facings and neckline facing onto wrong side, straighten, press. Slipstitch to garment along the shoulder seams.
6. Cut slit on sleeve along the marked line. Cut bias tape from main fabric (or take ready), its width should equal 4 cm and length should equal two lengths of slit +4 cm. Fold bias tape in half lengthwise and press. Press outer seam allowances towards center. Sew bias tape to slit of sleeve (pin bias tape to slit edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line).
7. Sew sleeve seam, press towards back and serge. Sew a gathering stitch along the lower edge of sleeve and along cap of sleeve and gather fullness. Sew sleeves into armholes, serge and press.
8. Pin together cuffs right sides together and sew short sides and sew longer side from corner up to mark. Trim away corners, near notches clip. Turn cuff right side out, straighten, press. Sew outer side of cuff to lower edge of sleeve. Fold inside inner side of cuff inside and stitch in the ditch.
9. Serge hem of garment, press onto wrong side and topstitch.
10. Make buttonholes on right front, sew on buttons on left front.

## **TECHNICAL DRAWING:**

