

Blouse With Decorative Sleeves - Sewing Pattern #2369

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 11 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Front placket - cut 2
4. Cuff - cut 4
5. Stand collar - cut 2
6. Collar - cut 2

Fusible interfacing:

1. Front placket – cut 2
2. Cuff – cut 2
3. Stand collar – cut 1
4. Collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back. Press bulk towards center. Sew center back seam. Serge seam and press towards left.
3. Sew dart on front. Press bulk towards top.
4. Press front placket in half lengthwise right side out. Sew inner side of placket to front, press seam allowances onto placket. Turn under the edge of outer placket and topstitch into the seam of inner placket. Sew a decorative stitch at 0.1 cm along the edge center front facings.
5. Sew shoulder seams, press seams towards back and serge. Sew side seams, press seams towards back and serge.
6. Pin together collars right sides together, sew ends and collar fall. Trim away corners. Turn the collar right side out, straighten and press. Sew a decorative stitch at 0.1 cm from the edge. Pin stand collars together right sides together, insert the ready collar between them and sew, sewing the ends of stand collar at the same time. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Turn finished collar right side out and press. Sew outer stand collar into neckline, fold inside open edge of internal stand collar and stitch in the ditch.
7. Serge the lower edge of upper sleeve. Serge the upper edge of lower sleeve. Fold under the one-piece placket of the lower sleeve and press and press. Sew a gathering stitch along the marked line and gather fullness. Pin lower sleeve onto upper sleeve, match seam allowances and topstitch. Sew sleeve edges separately. Sew seam from armhole to notch for slit. Press seam apart. Sew a fastening stitch along the slit at 0.2 cm from the edge. Sew sleeves into armholes. Serge and press. Sew a gathering stitch along lower edge of sleeve and gather fullness.
8. Pin pieces together cuffs pairwise right sides together and sew lower and shorter edges. Trim seam allowances. Turn cuff right side out, press. Sew outer side of cuff to sleeve, fold inside the seam allowance of inner cuff and stitch-in-the ditch into seam of outer cuff.
9. Make buttonholes on right front, sew on buttons on left front. Make button holes and sew on buttons on stand collar and cuffs.

TECHNICAL DRAWING:

