

## Raincoat With Attachable Hood - Sewing Pattern #2372

Recommendations on fabric: thick natural/mixed fabrics suitable for outdoor jackets

You will also need: fusible interfacing; 10 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Collar - cut 2
5. Stand collar - cut 2
6. Hood - cut 4
7. Hood tie - cut 4

8. Back neck facing – cut 1
9. Center front facing – cut 2
10. Large pocket bag – cut 2
11. Small pocket bag – cut 2
12. Off-set welt – cut 2
13. Decorative Tab – cut 2
14. Shoulder Strap – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Stand collar – cut 1
3. Center front facing – cut 2
4. Back neck facing – cut 1
5. Decorative Tab – cut 2
6. Shoulder Strap – cut 2
7. Off-set welt – cut 2

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Make and baste a box pleat on back.
3. Mark the pocket and apply fusible interfacing to this area. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags, serge.
4. Sew sleeve to back, press seam allowances towards sleeve, serge. Sew sleeve to front, press seam allowances towards sleeve, serge.
5. Fold tab in half lengthwise right sides together and sew the longer side and the shorter side. Trim seam allowances, turn tab right side out, press and sew a decorative stitch at 0.5 cm from the edge. Sew sleeve seam and side seam continuously, inserting decorative tab, serge and press.
6. Pin collars right sides together and sew corners and collar fall. Trim seam allowances, turn the collar right side out and press. Pin stand collars together right sides together, insert the ready collar between them and sew, sewing the ends of stand collar at the same time. Stand collar turn right side out and press.
7. Pin together shoulder strap in half lengthwise right sides together and sew the longer side and the shorter side. Trim seam allowances, turn right side out shoulder strap onto right side, press and sew a decorative stitch

at 0.5 cm from the edge. Sew the stand collar into neckline, inserting the raw edge of shoulder strap between the pieces.

8. Make buttonholes on the right center front facing. Sew shoulder seams of back neckline facing and center front facings, press seam apart. Serge outer edge. Pin center front facings and facing onto front, right sides together, and sew along center front edge and neckline. Turn buttonstnds (center front edges) right side out onto right side, straighten seams and press.

9. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

10. On left front sew on buttons. Make buttonholes on decorative tabs, sew on buttons correspondingly.

11. Make buttonholes on shoulder straps. Mark the center of shoulder strap and topstitch it onto sleeve across the shoulder. Fold shoulder strap towards neckline and sew a button corresponding to the button loop.

12. Sew together pieces of hood by two, press seam apart. Sew ties to hood. Pin hoods together right sides together and sew around all edges, leaving an opening for turning. Clip into curves. Turn the hood right side out, straighten, press. Sew the opening. Make buttonholes on hood neckline. Sew buttons onto the seam of stand collar.

## **TECHNICAL DRAWING:**

