

Jacket With Yoke - Sewing Pattern #2388

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; separating zipper; 2 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Upper front right - cut 1
3. Upper front left - cut 1
4. Lower front right - cut 1
5. Lower front left - cut 1
6. Back sleeve - cut 2

7. Front sleeve – cut 2
8. Collar – cut 1
9. Placket left – cut 1
10. Center front facing right - cut 1
11. Center front facing left - cut 1
12. Flap – cut 2
13. Back neck facing – cut 1
14. Decorative Tab – cut 2
15. Yoke – cut 1

Lining:

1. Back – cut 1 on fold
2. Front lining - cut 2
3. Back sleeve – cut 2
4. Front sleeve – cut 2
5. Yoke – cut 1

Attention! Back, Back Sleeve and Front Sleeve from lining are cut using pattern blocks for the main fabric except for the width of back neckline facing and front neckline facing correspondingly.

Fusible interfacing:

1. Collar – cut 1
2. Placket left – cut 1
3. Center front facing right - cut 1
4. Center front facing left - cut 1
5. Flap – cut 2
6. Back neck facing – cut 1
7. Decorative Tab – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on upper fronts, press bulk towards top.
3. Pin together flap in half lengthwise right sides together and sew short sides. Trim away corners, turn right side out flap onto right side, straighten, press. Pin flap according to markings at lower front and baste together along upper edge.
4. Sew upper front to lower front, press towards top and topstitch at 0.7 cm from seam.
5. Pin yoke to lining right sides together and sew along the center edge and the lower edge. Clip into curves, turn the piece right side out, straighten, press.

6. Pin the right part of zipper, right side down, onto right center front facing according to markings (the zipper teeth are directed towards the center front edge) and sew. Pin right center front facing to front right sides together and sew center front edge. Fold center front facing onto wrong side, straighten, press. Pin yoke onto right front and baste together along the sleeve seam.
7. Fold left placket in half lengthwise right sides together and sew lower corner. Turn the piece right side out, straighten, press. Pin left center front facing to front right sides together, inserting the placket and the left part of zipper, and sew center front edge. Fold center front facing onto wrong side, straighten, press.
8. Sew back sleeves to back, press seams towards back and topstitch at 0.7 cm from seam. Sew front sleeves to front, press towards front and topstitch at 0.7 cm from seam.
9. Fold tab in half lengthwise right sides together and sew longer edge and one shorter edge. Turn the piece right side out, straighten, press.
10. Sew upper edges of sleeves, press seams towards back. Sew lower edges of sleeves and side edges continuously, inserting decorative tab, press seams towards back.
11. Fold collar in half lengthwise right sides together and sew ends, trim away corners. Collar turn right side out and press.
12. Sew shoulder seams of buttonstands and facings, press seam apart. Baste center front facings and facing to the garment along the neckline edge. Sew outer edge of collar into neckline, press seam allowances at collar. Turn under the inner part of the collar and stitch-in-the-ditch along seam of outer side.
13. Sew seams on lining and sew in sleeves, leaving an opening for turning in the upper part of the left side seam. Sew lining to inner edges of center front facings and of facing.
14. Sew lining to hem of garment and hem of sleeves. Turn right side out, straighten. Sew the opening closed.
15. Make buttonholes on decorative tabs. Sew on buttons on sleeves correspondingly.

TECHNICAL DRAWING:

